

OME

SERIES

**Explosion-proof
Quarter-turn**

Electric Valve Actuators

SUNYEH

OPERATION MANUAL



SUNYEH ELECTRICAL IND. CO., LTD.

SY07-CA01A1-EN

Contents

1	General Information.....	1
1.1	Safety Instructions.....	1
1.2	Installation Notices.....	1
1.3	Working Conditions	4
1.4	Standards	4
1.5	Inspection, Storage, Transport.....	6
2	Product Overview	7
3	Product Mechanical Data.....	8
3.1	Parts Identification	8
3.2	Technical Information	9
3.3	Mounting Base Details.....	9
3.4	Actuator Selection.....	10
3.5	Sizing.....	10
3.6	Duty Cycle	11
3.7	Flamepath Joint	12
3.8	Nameplate Details	13
4	Mounting And Setup (OME-2 to OME-8).....	14
4.1	Manual Device Installation	14
4.2	Valve Mounting Instructions	15
4.3	Wiring Instructions.....	16
4.4	Actuator Set-up	17
5	Torque Switch.....	24
5.1	Instructions.....	24
6	Modulating Control Board Adjustment	25
6.1	OME-1, OME-A & OME-AM Modulating Control Board).....	25
6.2	Modulating Control Board (OME-2 to OME-8).....	44
7	Troubleshooting	52
8	Warranty.....	55
9	Disposal	55

1 General Information

⚠ Failure to follow safety instructions may cause serious injury, equipment damage, or voided warranty.

1.1 Safety Instructions

- Installation, maintenance and repair works must be performed by trained personnel.
- The handling shall follow the safety and warning instruction contained in this manual.
- Before operation, the user should read and follow instructions contained in this operation manual. Failure to do this may result in damages and void warranty. Sun Yeh will not be liable for damages due to operator negligence or misuse.
- Local health and safety legislation shall be complied with.
- In a few cases, the surface temperature may exceed 60°C (140 °F). Please check the surface temperature before operation, using an appropriate thermometer and wearing protective gloves before operation.

1.2 Installation Notices

- ⚠ All setting of opening the cover must be made in the safe place, prevent the spark from making the possibility of explosion.**
- ⚠ Operating by handwheel: Do not use excessive force when operating the handwheel as this can damage the actuator or valve.**

1.2.1 General

- DO NOT install in ambient temperatures that exceed 70 °C (158 °F).
- DO NOT, under any circumstances, remove the cover of the actuator while in a hazardous location when the power is still live inside the actuator. This could cause ignition of a hazardous atmosphere.
- DO NOT, under any circumstances, use an explosion-proof electric actuator in a hazardous location that does not meet the specification which the actuator was designed for.
- Mount, test, and calibrate actuators in non-hazardous location.
- When removing the actuator, care must be taken not to scratch, scar or deform the flame path of the cover or base of the actuator. That will negate the protection rating of the enclosure in a hazardous location.
- The explosion-proof electric actuator is shipped with mating surfaces of the cover and base. When assembling them, pay attention to the mating number (QA code) to assure the protection rating in a hazardous location.

【OME Series】 Explosion-proof Quarter-turn Valve Actuator

- Please read operation manual and wiring diagram carefully before installation.
- Verify that supply voltage is in accordance with the data on nameplate to prevent short circuit or electrical/electronic parts damage caused by incorrect power input.
- Turn power off before wiring or maintenance.
- There are grounding devices both inside and outside of the actuator and the ground wires should be connected properly.
- The metal plugs in conduit entries are for transit only. For long term protection fit suitable flameproof cable gland and power cable should be with a minimum withstand temperature 105 °C (221°F). Please refer to 1.2.3 (P.3).
- To avoid functional failure caused by static, do not touch any components on the PCBA with metal tools or bare hands.
- Do not parallel wire multiple actuators together without using an extra relay.
- Use suitable explosion-proof and water-proof cable glands to ensure it fits the conduit entry size, diameter of the cable and the enclosure protection of the actuator when wiring. The explosion-proof and water-proof cable glands must be tightened and flattened to the cable after wiring procedure. Do not remove the explosion-proof and water-proof metal plugs from unused conduit entry, be sure to fasten the top cover of the actuator to reach explosion-proof and water-proof function.
- Actuator should be installed in an upright or horizontal position. Do not mount upside down or below a horizontal position.
- Periodically inspect actuator enclosure to prevent dust from accumulating.
- Perform below inspections prior to installation. Not allowed to adopt if any item is unqualified.
 - ✓ Check the marking and certificate number to see if it conforms to the indicated application.
 - ✓ All the parts of the housing are assembled in the right manner and fastened.
⚠ USE FASTENERS WITH YIELD STRESS \geq 450 MPa.
 - ✓ All the explosion-proof parts should be made without cracks or functional defects.

1.2.2 CSA Certification Considerations

- KEEP COVER TIGHT WHILE CIRCUITS ARE ALIVE.
 - ⚠ **AFTER DE-ENERGIZING, DELAY 10 MINUTES BEFORE OPENING THE COVER.**
- SEAL REQUIRED WITHIN 18 INCHES (450 mm) OF ENCLOSURE (for Divisions only).
- SEAL REQUIRED WITHIN 2 INCHES (50 mm) OF ENCLOSURE (for Zones only).

1.2.3 Cable Glands

⚠ **Please select the relatively explosion-proof cable connector according to the product specifications and Loctite 577 sealant is recommended for NPT cable glands to achieve IP rating.**

- **ATEX / UKEX / IECEx / JPEX/ TS Certification :**
 - ✓ The actuator is delivered with two conduit entries plugged by metal plugs. Use cable glands with ATEX / UKEX / IECEx / JPEX / TS certification and in accordance with the technical characteristics required by Ex db IIB Gb, Ex tb IIIC Db. The electrical supply cable must be suitable for power rating and with a minimum withstand temperature 105 °C (221 °F).
- **CNEx / CCC Certification :**
 - ✓ The actuator is delivered with two conduit entries plugged by metal plugs. Use cable glands with CNEx certification and in accordance with the technical characteristics required by CNEx Ex db IIB T4 Gb, Ex tb IIIC T130 °C Db The electrical supply cable must be suitable for power rating and with a minimum withstand temperature 105 °C (221 °F).
- **CSA Certification :**
 - ✓ The actuator is delivered with two conduit entries plugged by metal plugs. Use cable glands with CSA certification. The electrical supply cable must be suitable for power rating and with a minimum withstand temperature 105°C (221 °F).

1.3 Working Conditions

- **ATEX / UKEX / IECEX / JPEX / CNEEx / CCC / TS Certification :**
 - ✓ Atmospheric pressure : 80 - 110 kPa.
 - ✓ Ambient temperature : - 30 °C to + 70 °C (- 22 °F to + 158 °F).
 - ✓ Relative humidity : Not more than 95 % (+ 25 °C / 77 °F).
 - ✓ The actuator can operate normally within tolerated variation of ± 10% of rated supply voltage or ± 1% of rated frequency.

- **CSA Certification :**
 - ✓ Atmospheric pressure : 80 - 106 kPa.
 - ✓ Ambient temperature : -30 °C to +70 °C (-22 °F to +158 °F).
 - ✓ Air with normal oxygen content : 21 % (Volume).

1.4 Standards

- **ATEX European Hazardous Area:** EN60079-0, EN60079-1, EN60079-31

Directive	Group	Ambient Temperature
ATEX II 2 GD	Ex db IIB T4 Gb	- 30 °C to + 70 °C (- 22 °F to + 158 °F)
ATEX II 2 GD	Ex tb IIIC T130 °C Db	- 30 °C to + 70 °C (- 22 °F to + 158 °F)

- **UKEX Great Britain Hazardous Area ^{UK}CA:** EN60079-0, EN60079-1, EN60079-31

Directive	Group	Ambient Temperature
UKCA II 2 GD	Ex db IIB T4 Gb	- 30 °C to + 70 °C (- 22 °F to + 158 °F)
UKCA II 2 GD	Ex tb IIIC T130 °C Db	- 30 °C to + 70 °C (- 22 °F to + 158 °F)

- **IECEX International Hazardous Area:** IEC 60079-0, IEC 60079-1, IEC60079-31

Group	Ambient Temperature
Ex db IIB T4 Gb	- 30 °C to + 70 °C (- 22 °F to + 158 °F)
Ex tb IIIC T130 °C Db	- 30 °C to + 70 °C (- 22 °F to + 158 °F)

- **CSA North American Hazardous Area:**

- ✓ **Zone System:**

CAN/CSA-C22.2 No. 60079-0, CAN/CSA-C22.2 No. 60079-1, CAN/CSA-C22.2 No. 60079-31, ANSI/UL 60079-0, ANSI/UL 60079-1, ANSI/UL 60079-31

Code	Hazard Class	Permitted Zone	Type of Protection	Groups	Temp Classification	Ambient Temperature
AEx / Ex	I	1	db	IIB, IIA	T4	- 30 °C to + 70 °C (- 22 °F to + 158 °F)
AEx / Ex	II	21	tb	IIIC, IIIB, IIIA	T130°C	- 30 °C to + 70 °C (- 22 °F to + 158 °F)

【 OME Series 】 Explosion-proof Quarter-turn Valve Actuator

✓ **Division System:**

CSA C22.2 No. 30-M1986, CSA C22.2 No. 25-17, FM 3600, FM 3615, FM 3616

Hazard Class	Permitted Division	Groups	Temp Classification	Ambient Temperature
I	1	C,D	T4	- 30 °C to + 70 °C (- 22 °F to + 158 °F)
II	1	E,F,G	T130°C	- 30 °C to + 70 °C (- 22 °F to + 158 °F)

● **CNEx / CCC Certification:** GB/T 3836.1, GB/T 3836.2, GB/T 3836.31

Group	Ambient Temperature
Ex db IIB T4 Gb	- 30 °C to + 70 °C (- 22 °F to + 158 °F)
Ex tb IIIC T130 °C Db	- 30 °C to + 70 °C (- 22 °F to + 158 °F)

● **TS Certification:** IEC 60079-0, IEC 60079-1, IEC60079-31

Group	Ambient Temperature
Ex db IIB T4 Gb	- 30 °C to + 70 °C (- 22 °F to + 158 °F)
Ex tb IIIC T130°C Db	- 30 °C to + 70 °C (- 22 °F to + 158 °F)

● **JPEX Japanese Hazardous Area:** JNIOSH-TR-46-1, JNIOSH-TR-46-2, JNIOSH-TR-46-9

Group	Ambient Temperature
Ex db IIB T4 Gb	- 30 °C to + 70 °C (- 22 °F to + 158 °F)
Ex tb IIIC T130°C Db	- 30 °C to + 70 °C (- 22 °F to + 158 °F)

1.5 Inspection, Storage, Transport

1.5.1 Receiving / Inspection

- Carefully inspect the package for any damages resulting from shipping and report all damages to the freight carrier and seller.
- After unpacking the product and information packet, please keep the cartons and any packing materials in case of product return or replacement. Verify that the items listed in packing slip or in bill of lading are the same as what were ordered. If there is any discrepancy, please contact the seller.
- Verify that the technical data on nameplate is in accordance with what was ordered.

1.5.2 Storage

- The actuator should be stored in a dry area with relative humidity of less than 90 % and at temperature between -20 °C to + 40 °C (-4 °F to + 104 °F).
- The product shall be stored with suitable protection from corrosive substance that can damage the metal and insulating parts.
- The metal plugs for temporary protection should not be removed until the actuator is ready to be cabled. Use suitable flameproof cable glands to ensure IP rated protection when installing. Please refer to 1.2.3 (P.3).

1.5.3 Transport

- Attach ropes or hooks for the purpose of lifting by hoist only to housing and not to handwheel.
- Actuators packaged in cartons can stand up to land, sea, or air transportation.
- Packaged actuators shall avoid of violent impact and strong vibrations and be protected from rain or snow.


1.5.4 Lubrication

- The gear train has been sufficiently lubricated at the factory. No additional lubrication is required.

2 Product Overview

OME series explosion-proof quarter-turn electric actuators are structured as flame-proof and combustible dust-proof and offer torque ranges from 35 Nm to 1,500 Nm (310 in-lb to 13,280 in-lb). Product design is based on a self-locking worm drive principal, which provides for a smooth running, dependable, robust drive system. All models are ISO 5211 compliant, have a visual position indicator on top of actuator cover and manual override except OME-A. The manual operation is non-clutch design that can be operated without any lever, clutch or brake upon power outage.

- **ATEX / UKEX / IECEx / JPEX / CNEx / TS Explosion-proof instructions :**

 **II 2 GD Ex db IIB T4 Gb, Ex tb IIIC T130°C Db IP66, IP68**

- ✓ OME series Explosion-proof Quarter-turn Electric Valve Actuator (referred as "actuator") is a control device for valves and can be used in the places, where is classified as Zone 1 or Zone 2, contained Group II A and Group II B gases, Zone 21 or Zone 22, contained the combustible dust atmosphere or the mixture circumstance with the explosive gas atmospheres and the combustible dust atmospheres. Temperature group T1-T4.

- **Certificate Number :**

Sira17ATEX1243X

IECEx SIR17.0062X

CNEx22.5068X (CCC : 2020312307000188)

(ITIR) 2018 No.07-00013X

CSAE 21UKEX1207X

CSAUK 21JPN036X (JPEX - Gas)

CSAUK21JPN037 (JPEX - Dust)

- **CSA explosion-proof instructions :**

- ✓ **Division System** where is classified as North American Division 1 or Division 2 of hazardous location, contains Group C and Group D gases and temperature group T1 - T4; or contains one or several flammable dusts with minimum flaming point over 130 °C; or include both above flammable gases and dusts.

- ✓ **Zone System** where is classified as North American Zone 1 or Zone 2 of hazardous location, contains Group II A and Group II B gases and temperature group T1 - T4; or in Zone 21 or Zone 22, contained one or several flammable dusts with the minimum flaming point over 130 °C; or include both above flammable gases and dusts.

- **Certificate Number :**


70156877

2.1 Features

- Enclosure conforms to the following standard: IP66, IP68 (7 m / 72 hrs)
- Self-locking gear system.
- ISO 5211 mounting flange.
- Flatted position indication.
- Mechanical stops (except OME-1 / A / AM).
- Clutch-less manual override.
- Built-in thermal protection.

3 Product Mechanical Data


3.1 Parts Identification



3.2 Technical Information

Model	Max.Torque		Weight		Moto Power	Manual Override	Flange Type
	Nm	in-lb	kg	lb	W		ISO 5211
OME-1	35	310	2	4	10	Lever	F03 / F05
OME-AM	50	445	3	7	10		F07
OME-A	50	445	3	7	10		N/A
OME-2	90	800	18	40	40	Handwheel	F07
OME-3	150	1330	18	40	40		F07
OME-4	400	3540	31.5	69.5	80		F10
OME-5	500	4430	31.5	69.5	80		F10
OME-6	650	5755	31.5	69.5	80		F10
OME-7	1000	8855	46	101	120		F12 or F14
OME-8	1500	13280	46	101	120		F12 or F14

3.3 Mounting Base Details



Model	Flange Type	Output Drive (A)		Depth of Output Drive (B)	
	ISO 5211	mm	inch	mm	inch
OME-1	F03 / F05	14	0.551	17	0.669
OME-A	F07	17	0.669	20	0.787
OME-AM	F07	17	0.669	20	0.787
OME-2 to OME-3	F07	22	0.866	30	1.181
OME-4 to OME-6	F10	36	1.417	48	1.889
OME-7 to OME-8	F12 or F14	36	1.417	50	1.968

3.4 Actuator Selection

OME- ① - ② - ③ - ④

① Type	② Voltage	③ Control Mode	④ Duty cycle
A AM 1 2 3 4 5 6 7 8	D12 : 12 V DC 24 : 24 V AC D24 : 24 V DC 120 : 110 - 120 V AC 1PH 220 : 220 - 240 V AC 1PH	F : Floating M : Modulating	30 : 30 % 75 : 75 %

3.5 Sizing

- a. The actuator shall be sized to ensure that its torque output meets the load requirements of valve and its ability to overcome the required duty cycle of application (As a MINIMUM, a 30% safety factor is suggested for the calculation of torque requirement).

- If the maximum torque of 5" valve is 80 Nm $\rightarrow 80 \times 1.3$ (safety factor) = 104 Nm
104 Nm < 150 Nm (OME-3) \rightarrow OK!
 104 Nm > 90 Nm (OME-2) \rightarrow Not OK!

- b. In cases where the actuator does not directly fit onto the valve, a mounting kit is required. Please ensure the bracket and coupling are properly designed and manufactured to with stand the torque output of the actuator.

3.6 Duty Cycle

- The standard duty cycle for OME series is 30% or 75% is for option. The duty cycle is the relationship between the running time and resting time. It is calculated as below:

$$\text{Duty Cycle} = \frac{\text{Running Time (Sec)}}{\text{Running Time (Sec)} + \text{Rest Time (Sec)}} \times 100 \%$$

$$\Rightarrow \text{Rest Time (Sec)} = \frac{\text{Running Time (Sec)} \times (1 - \text{Duty Cycle})}{\text{Duty Cycle}}$$


- If the running time for OME-2 is 15 sec, 30% duty cycle, the rest (off) time shall be calculated as below:
 $\rightarrow 15 \times [(1 - 30\%) / 30\%] = 35$ The rest time will be 35 sec.
- If the running time for OME-2 is 15 sec, 75% duty cycle, the rest (off) time shall be calculated as below:
 $\rightarrow 15 \times [(1 - 75\%) / 75\%] = 5$ The rest time will be 5 sec.

Note: For higher duty cycles, choose the 75% duty cycle.

⚠ One cycle consists of open-rest-close-rest.

3.7 Flamepath Joint

- ⚠ During cover removal and conduit entry removal, ensure that surfaces are free from scratches or scrapes.**
- ⚠ Actuator installation and maintenance must be performed by trained personnel.**



Cover Removal

Remove the conduit entry metal plugs to relieve the pressure inside the actuator for the ease of the top cover removal and gently remove the cover. DO NOT attempt to remove the top cover with a screwdriver as it will damage the surfaces.

Cover Installation

- ⚠ Please ensure that the O-ring seal is in good condition prior to cover installation. Slowly re-install the cover while being careful not to pinch the O-ring seal.**
- ⚠ The explosion-proof enclosures are labeled with a QA code on both of the middle plate and the cover, please verify the QA code inside the cover is the same as the one on middle plate when installation. The cover is not interchangeable.**





Please follow this table to tighten the cover screw:

Model	Screw	Allen Key	Torque
		mm	Nm
OME-A, OME-AM & OME-1	M6	5	8
OME-2 to OME-3	M10	8	43
OME-4 to OME-8	M12	10	75




【 OME Series 】 Explosion-proof Quarter-turn Valve Actuator

3.8 Nameplate Details





⚠ Please make sure the explosion-proof specification for the product is consistent with nameplate and instruction.

			
<ol style="list-style-type: none"> Model No. : Running Time: Sec/90° Torque: N·m Enclosure Rating: IP66 - IP68 (72 h, 7 m) Motor Power: W Supply Voltage: Rated Current: A Serial No. : Date of Manufacture: 	<ul style="list-style-type: none"> The metal conduit plugs are for transit purposes only. For long term protection, fit and tighten suitable flameproof and watertight cable glands. The withstand temperature of the cable shall not less 105°C (221°F). See instructions for cable entry threading. DO NOT OPEN WHEN ENERGIZED. AFTER ISOLATING POWER, DELAY 10 MINUTES BEFORE REMOVING COVER. Extreme care should be taken when removing cover as to not damage the flame path. See instructions on how to avoid any electrostatic charging hazards. USE FASTENERS WITH YIELD STRESS ≥ 450MPa. 		
 		II 2G Ex db IIB T4 Gb II 2D Ex tb IIIC T130°C Db -30°C ≤ Tamb ≤ +70°C IP66 IP68 SIRA I7ATEX1243X IECEx SIR 17.0062X CSAE 21UXE1207X	

ATEX, UKEX & IECEx

			
<ol style="list-style-type: none"> Model No. : Running Time: Sec/90° Torque: N·m Enclosure Rating: Type 4X Motor Power: Supply Voltage: Rated Current: A Ambient Temp: - °C to + °C Serial No. : Date of Manufacture: 	<ul style="list-style-type: none"> Please review Operat or Manual s/c Wiring Diagram carefully before installation. DO NOT OPEN WHEN ENERGIZED. The metal plugs in conduit entries are for transit only. For long term protection, fit and tighten suitable flameproof and watertight cable glands. The withstand temperature of the cable shall not less 105°C (221°F). COMDUIT SEAL WITHIN 18" (457mm) OF ENCLOSURE For Zone Classification only. COMDUIT SEAL WITHIN 2" (50 mm) OF ENCLOSURE For Zone Classification or only. AFTER ISOLATING POWER, DELAY 10 MINUTES BEFORE REMOVING COVER. USE FASTENERS WITH YIELD STRESS ≥ 450MPa. Realisez les attentivement a mesure d'installation et le scieria de cibage avec l'isolacion. NE PAS SAUVIR L'OSERVALIEME. Les boucous metaliques dans les entrees de conduits sont uniquement destines au transit. Pour une protection a long terme, fixed et tighten les pressostatics appropries, en utilisant un al abrashes. La temperature que peut supporter le cable ne doit pas etre inferieure a 105°C (221°F). Sosau ce conduit installe en-cet de 50 mm de l'unit (Classification var Zone enqubnement). Sosau ce conduit installe en-cet de 50 mm de l'unit (Classification var Zone enqubnement). AVOIR COLTE L'ALIMENTATION AVANT D'OUVRIR LE COUVERCLE. Ne laissez pas des attaches avec une limite d'elasticite en traction a 450MPa. 		
		Class I, Division 1, Groups C, D T4 Class II, Division 1, Groups E, F, G T130°C Type 4X Ex db IIB T4 Gb (For Canada) Class I, Zone 1, AEx db IIB T4 Gb (For US) Ex to IIIC T130°C Db (For Canada) Zone 21, AEx to IIIC T130°C Db (For US) IP66, IP68 (72h, 7m) CSA 18.70J5687X	




CSA

			
<ol style="list-style-type: none"> Model No. : Running Time: Sec/90° Torque: N·m Enclosure Rating: IP66 - IP68 (72 h, 7 m) Motor Power: W Supply Voltage: Rated Current: A Serial No. : Date of Manufacture: 	<ul style="list-style-type: none"> The metal conduit plugs are for transit purposes only. For long term protection, fit and tighten suitable flameproof and watertight cable glands. The withstand temperature of the cable shall not less 105°C (221°F). See instructions for cable entry threading. DO NOT OPEN WHEN ENERGIZED. AFTER ISOLATING POWER, DELAY 10 MINUTES BEFORE REMOVING COVER. Extreme care should be taken when removing cover as to not damage the flame path. See instructions on how to avoid any electrostatic charging hazards. USE FASTENERS WITH YIELD STRESS ≥ 450MPa. 		
 		Ex db IIB T4 Gb Ex tb IIIC T130°C Db -30°C ≤ Tamb ≤ +70°C	

TS

			
<ol style="list-style-type: none"> 型号: 运转时间: Sec/90° 扭力: N·m IP等级: IP66 (72h, 7m), IP66 马达功率: W 供给电压: 额定电流: A 生产序号: 制造日期: 	<ul style="list-style-type: none"> 金属堵头仅用于运输时使用。配线时安装合适的Ex电缆引入装置并按规范拧紧。电缆耐温不低於105°C (221°F)。 电缆引入装置尺寸-具使用说明书。 拆线执行时，须注意外壳隔爆接合面请勿刮伤、刮伤或变形，否则可能影响外壳防爆性能。 使用屈服应力≥450MPa的紧固件。 警告：潜在静电电荷危险-见使用说明书。 警告：严禁带电开盖。 警告：断电后，10分钟方可开盖。 		
 		Ex db IIB T4 Gb Ex tb IIIC T130°C Db CNEx22.5068X	

CCC & CNEx

			
<ol style="list-style-type: none"> 型式コード: 開閉時間: Sec/90° トルク: N·m 保護等級: IP66、IP68 (72 h, 7 m) モーター出力: W 電源: 定格電流: A シリアル番号: 製造年月: 	<ul style="list-style-type: none"> 金属口の金属製プラグは運送時のみ使用されます。 長期にわたる保護等級と防水等級に適合するケーブル、ドクタを使用し、しっかりと締め付けください。 以上が保証期間(105°C (221°F)以上のケーブルは保証期間外となります。 ケーブルコネクタの仕様について、取扱説明書をご確認ください。 遮断中、アクチュエータカバーは絶対に触れないでください。 アクチュエータカバーは、電源を切り10分間してから取り外し可能です。 アクチュエータカバーを取り外す時に、カバーと本体ベースの接合部に力がかかり、変形させたりしないようご注意ください。 静電気に係る危険の防止について、取扱説明書をご確認ください。 電機耐力が50 MPa以上のファスナーをご利用ください。 		
		Ex db IIB T4 Gb IP66 IP68 -30°C ≤ Tamb ≤ +70°C CSAUK 21JPN036X	

JPEX - Gas

			
<ol style="list-style-type: none"> 型式コード: 開閉時間: Sec/90° トルク: N·m 保護等級: IP66、IP68 (72 h, 7 m) モーター出力: W 電源: 定格電流: A シリアル番号: 製造年月: 	<ul style="list-style-type: none"> 金属口の金属製プラグは運送時のみ使用されます。 長期にわたる保護等級と防水等級に適合するケーブル、ドクタを使用し、しっかりと締め付けください。 以上が保証期間(105°C (221°F)以上のケーブルは保証期間外となります。 ケーブルコネクタの仕様について、取扱説明書をご確認ください。 遮断中、アクチュエータカバーは絶対に触れないでください。 アクチュエータカバーは、電源を切り10分間してから取り外し可能です。 アクチュエータカバーを取り外す時に、カバーと本体ベースの接合部に力がかかり、変形させたりしないようご注意ください。 静電気に係る危険の防止について、取扱説明書をご確認ください。 		
		Ex tb IIIC T130°C Db IP66 IP68 -30°C ≤ Tamb ≤ +70°C CSAUK 21JPN037	

JPEX - Dust


Nameplate Indication			
① Model No.	② Running Time	③ Torque	④ Enclosure Rating
⑤ Motor Power	⑥ Supply Voltage	⑦ Rated Current	⑧ Serial No.
⑨ Date of Manufacture	⑩ Ambient Temp.	⑪ Warning	

4 Mounting And Setup (OME-2 to OME-8)

4.1 Manual Device Installation


- a. Pass the screw through the handle and tighten the nut onto handwheel.

⚠ Do not overtighten.




- b. Secure the handle to the wheel with the slotted screw and tighten the locknut all the way down to the wheel. Ensure that the locknut is locked between the wheel and the handle.

⚠ Leave a 2 mm gap between the locknut and the handle as the figure below to allow the handle free to rotate and then to have a smooth manual operation.




- c. Slide fixing screw through washers and handwheel and secure them to override shaft as shown in the figure below.

⚠ Turn off power when installing handwheel.




- d. Assembly completed as shown in the figure below.



OME-1 & OME-AM


OME-1



Use a 8 mm wrench to rotate the shaft.
Max. torque : 5 Nm

Manual Position

OME-AM




Use a 5 mm wrench to rotate the shaft.
Max. torque : 5 Nm

Manual Position

4.2 Valve Mounting Instructions

- a. Make sure both the valve and actuator are in the same position before mounting, either fully-open or fully-closed. If not, use the manual override to correct this.
- b. Once mounted together, either directly or with a mounting kit, ensure that they are properly secured together and all fasteners are tightened.
 - ⚠ **Remove all of valve handle parts, for example, the handle or open/close mechanical stops so as to not interfere with the actuator.**
- c. Check again that the valve and actuator are in the same position.
- d. Remove the conduit entry plug to relieve the pressure inside the actuator for the ease of the top cover removal and gently remove the cover, please refer to 3.7 (P.12) for cover installation.
 - ⚠ **The power must be off before removing the cover.**
 - ⚠ **AFTER DE-ENERGIZING, DELAY 10 MINUTES BEFORE OPENING THE COVER.**
- e. Refer to section 4.3 (P.16) for wiring notices and connect the wires according to the wiring diagram labeled inside the cover of actuator.
- f. Supply power to actuator.
 - ⚠ **Care must be taken at all times as there are live circuits present that may cause electrical shock.**
- g. Re-calibration may be required for the end positions, refer to 4.4 (P.17) for further instructions.
- h. For modulating units, refer to section 6 (P.25 - P.51) for setting instructions.
 - ⚠ **Use the insulated wires and length should be less than 30 m.**
 - ⚠ **A minimum of 18 AWG wire is recommended for all field wiring.**
 - ⚠ **Turn power off before changing any settings.**
- i. Assemble the cover and secure cover screws firmly after setting.
 - ⚠ **Refer to 3.7 (P.12) for installation and check if there is any foreign object between top cover flamepath joint and base.**
 - ⚠ **Please ensure that the O-ring seal is in good condition prior to cover installation.**
 - ⚠ **The explosion-proof enclosures are labeled with a QA code on both of the middle plate and the cover, please verify the QA code inside the cover is the same as the one on middle plate when installation. The cover is not interchangeable.**



4.3 Wiring Instructions

⚠ Turn power off before making the electrical connection!

- There are grounding devices both inside and outside of the actuator (green screw) and wiring according to the wiring diagram inside the top cover.
- The conduit entries are attached two conduit entries plugged by metal plugs, and the specification as below. Each actuator is attached with two metal plugs to conduit entries.
OME-A, OME-AM and OME-1: 1/2" NPT, M20.
OME-2 to OME-8: 3/4" NPT, 1/2" NPT, M20, M25.
⚠ Use correct size of fittings so as to not damage the threads.
- Verify the supply power is in accordance with the data on the nameplate to prevent a short circuit and an electrical shock.
⚠ Do not apply power to actuator before wiring, otherwise it can cause an electrical shock or damage components of the actuator.
- After wiring, please tighten the conduit entries with suitable cable glands and cover properly. Unused conduit entries have to be sealed with metal plugs to reach explosion-proof function. Please refer to 1.2.2 - 1.2.3 (P.3).
⚠ Relating to OME series with Japanese explosion-proof certification, it is mandatory to select the cable gland of A2F series made by CMP Products Ltd to meet Japanese explosion-proof standards.
⚠ Loctite 577 sealant is recommended for NPT metal plugs or cable glands to achieve IP rating.


4.4 Actuator Set-up

- ⚠ The power must be off during this procedure so as to avoid damage to the actuator.**
- ⚠ Do not make adjustments to the mechanical end stops when actuator is in motion.**
- ⚠ All steps below must be completed before normal operation.**

The actuators have been set and calibrated at the factory. Most of products will not require recalibration of these settings. However these are general settings. After valve and actuator are bolted together, apply power to verify the end positions are correct. If an adjustment is required, please follow steps below. When the actuator is equipped with modulating controller, signal setting for open and close position has to be re-set accordingly, please refer to 6.1.5 and 6.2.5.

4.4.1 Instructions

- The travel cams are set to control the open and closed position of the actuator. See below procedure for corresponding actuator model:
 OME-1, OME-A and OME-AM : The position is set to stop the travel of the actuator when the travel cams activate the limit switch.
 OME-2 to OME-8 : The position is set to stop the travel of the actuator when the travel cams don't activate the limit switch.
- The standard is with two limit switches (LS1 & LS2).
 LS1 & LS2: LS1 is for open and LS2 is for close. They limit the fully-open and fully-closed travel range by disabling the electric motor.
 LS3 & LS4 are optional. They allow external equipment to confirm that the valve has reached the fully-open and fully-closed positions.
⚠ LS3 (LS4) should activate before LS1 (LS2).



- Dry contact sequence diagram (LS3 & LS4)

【 OME-1, OME-A, OME-AM 】

Symbol	Contact	Position	
		100%	0%
LS4 (Dry Contact)	A - F	—●—	- - - - -
	A - E	- - - - -	—●—
LS3 (Dry Contact)	A - C	—●—	- - - - -
	A - B	—●—	- - - - -



【 OME-2 ~ OME-8 】

Symbol	Contact	Position	
		100%	0%
LS4 (Dry Contact)	D - F	- - - - -	—●—
	D - E	—●—	- - - - -
LS3 (Dry Contact)	A - C	—●—	- - - - -
	A - B	—●—	- - - - -

- Solid line (—) : Dry contact in conductive state.
- Dotted line (- - - - -) : Dry contact in non-conductive state.

4.4.2 Adjustment Steps



- a. Turn power off.
- b. When optioned with modulating control or potentiometer, loosen the set screw on the sector gear or round gear.



【 OME-1 、 OME-A 、 OME-AM 】

【 OME-2 to OME-8 】

- c. OME-A, OME-AM (Fully-open Position / Feedback Signal Adjustment)



Direction	Travel Cams	Instructions
Closed	TC2	↻ Clockwise: increase closing degree.
	TC4 (Optional)	↻ Counter-clockwise: decrease closing degree.
Open	TC1	↻ Clockwise: decrease opening degree.
	TC3 (Optional)	↻ Counter-clockwise: increase opening degree.

1. Loosen the M5 set screw of cam TC1 with a 2.5 mm Allen Key.

TC1 (Fully-open Position):

- Adjust the cam according to the required position.
 - Increase the fully-open degree: rotate the cam TC1 **counter-clockwise**.
 - Decrease the fully-open degree: rotate the cam TC1 **clockwise**.
- After the adjustment is completed, please securely tighten the cam TC1.
- Apply power to check if the fully-open position is correct. If it is not correct, please repeat the steps above.

TC3 (Feedback Signal):

- Before the adjustment, please complete the TC1 (Fully-open position) adjustment steps first.
- Slowly rotate the cam TC3 **counterclockwise** until it triggers the limit switches and a light click is heard. Then, rotate the cam TC3 **clockwise** until a light click is heard. Afterward, fine-tune the degree **clockwise** slightly and then tighten cam TC3.

 **TC3 should trip one second before TC1.**

 **This step is applicable to the two optional auxiliary limit switches.**

2. After the adjustment is completed, check again that the set screw is securely tightened.

d. OME-A, OME-AM (Fully-Closed Position / Feedback Signal Adjustment)

1. Loosen the M5 set screw of cam TC2 with a 2.5 mm Allen Key.

TC2 (Fully-closed Position):

- Adjust the cam according to the required position.
 - Increase the fully-closed degree: rotate the cam TC2 clockwise.
 - Decrease the fully-closed degree: rotate the cam TC2 counter-clockwise.
- After the adjustment is completed, please securely tighten the cam TC2.
- Apply power to check if the fully-closed position is correct. If it is not correct, please repeat the steps above.

TC4 (Feedback Signal):

- Before the adjustment, please complete the TC2 (Fully-closed position) adjustment steps first.
- Slowly rotate the cam TC4 **clockwise** until it triggers the limit switches and a light click is heard. Then, rotate the cam TC4 **counter-clockwise** until a light click is heard. Afterward, fine-tune the degree **counter-clockwise** and then tighten the cam TC4.

 **TC4 should trip one second before TC2.**


 **This step is applicable to the two optional auxiliary limit switches.**





2. After the adjustment is completed, check again that the set screw is securely tightened.

【 OME Series 】 Explosion-proof Quarter-turn Valve Actuator


e. OME-1 to OME-8 (Fully-open Position / Feedback Signal Adjustment)





● OME-1



Direction	Travel Cams	Instructions
Closed	TC2 TC4 (Optional)	 Clockwise: decrease closing degree.  Counter-clockwise: increase closing degree.
Open	TC1 TC3 (Optional)	 Clockwise: increase opening degree.  Counter-clockwise: decrease opening degree.


● OME-2 to OME-8



Direction	Travel Cams	Instructions
Closed	TC2 TC4 (Optional)	 Clockwise: decrease closing degree.  Counter-clockwise: increase closing degree.
Open	TC1 TC3 (Optional)	 Clockwise: increase opening degree.  Counter-clockwise: decrease opening degree.

【 OME Series 】 Explosion-proof Quarter-turn Valve Actuator

1. Remove the cover.
2. Loosen the locknut and unwind **Open** Mechanical end stop screws for 7 turns.
⚠ Manual device setting is available for OME-2 to OME-8.
3. Use the manual override to turn the valve to fully-open position.
4. Loosen the cam screw:
 - OME-1: Loosen the M5 set screw of cam TC1 with a 2.5 mm Allen Key.
 - OME-2 to OME-8: Loosen the M3 set screw of cam TC1 with a 2.5 mm Allen Key.



TC1 (Fully-open Position):

- Slowly rotate the cam TC1 **clockwise** until the limit switch is triggered and a light click is heard. Then, rotate the cam TC1 **counter-clockwise** until a light click is heard, and then tighten the cam TC1.
- Apply power to check if the fully-open position is correct. If it is not correct, please repeat the steps above.

TC3 (Feedback Signal):

- Before the adjustment, please complete the TC1 (Fully-closed Position) adjustment steps first.
- Slowly rotate the cam TC3 **clockwise** until it triggered the limit switch and a light click is heard. Then rotate the cam TC3 **counter-clockwise** until a light click is heard. Afterward, fine-tune the degree **counter-clockwise** and then tighten the cam TC3.

⚠ TC3 should trip one second before TC1.


⚠ This step is applicable to the two optional auxiliary limit switches.

5. After the adjustment is completed, check again that the set screw is securely tightened.

【 OME Series 】 Explosion-proof Quarter-turn Valve Actuator

f. OME-1 to OME-8 (Fully-closed Position / Feedback Signal Adjustment)

1. Remove the cover.
2. Loosen the locknut and unwind **Close** Mechanical end stop screws for 7 turns.
⚠ Manual device setting is available for OME-2 to OME-8.
3. Use the manual override to turn the valve to fully-closed position.
4. Loosen the cam screw:
 - OME-1: Loosen the M5 set screw of cam TC2 with a 2.5 mm Allen Key.
 - OME-2 to OME-8: Loosen the M3 set screw of cam TC2 with a 2.5 mm Allen Key.



TC2 (Fully-closed Position):

- Slowly rotate the cam TC2 **counter-clockwise** until it triggered the limit switch and a light click is heard. Then, rotate the cam TC2 **clockwise** until a light click is heard and tighten the cam TC2.
- Apply power to check if the fully-closed position is correct. If it is not correct, please repeat the steps above.

TC4 (Feedback Signal):

- Before the adjustment, please complete the TC2 (Full-closed Position) adjustment steps first.
- Slowly rotate the cam TC4 **counter-clockwise** until the limit switch is triggered, and a light click is heard. Then, rotate the cam TC4 **clockwise** until a light click is heard. Afterward, fine-tune the degree **clockwise** and then tighten the cam TC4.

⚠ TC4 should trip one second before TC2.


⚠ This step is applicable to the two optional auxiliary limit switches.

5. After the adjustment is completed, check again that the set screw is securely tightened.
- g. Supply power to the fully-open position. Screw in the **Open** (left) Mechanical end stop screw until it bottoms out (refer to e of P.21), then turn back for 1/2 or 1 turn based on the actuator model listed below.
- OME-2 to OME-3: 1 turn
 - OME-4 to OME-8: 1/2 turn
- h. Tighten the locknut. (Max. Torque: 5.88 Nm)


【OME Series】 Explosion-proof Quarter-turn Valve Actuator

- i. Supply power to the fully-closed position. Screw in the Close (right) mechanical end stop screw until it bottoms out (refer to f of P.22), then turn back for 1/2 or 1 turn based on the actuator model listed below.
 - OME-2 to OME-3: 1 turn
 - OME-4 to OME-8: 1/2 turn
- j. Tighten the locknut. (Max. Torque: 5.88 Nm)
- k. Supply the power to confirm that the limit switches achieve the fully open-close stroke.
- l. When optional with modulating control or potentiometer:
Supply power to run the actuator to the fully-closed position and tighten the set screw based on the actuator model listed below.

OME-A, OME-AM	Rotate the round gear counter-clockwise to the end and tighten the M5 set screw.
OME-1	Rotate the round gear clockwise to the end and tighten the M5 set screw.
OME-2 to OME-8	Rotate the sector gear clockwise to the end and tighten the M5 set screw.



【OME-1, OME-A, OME-AM】




【OME-2 to OME-8】

- m. The setting procedure is now completed.

5 Torque Switch

5.1 Instructions

- The standard is with two torque switches (TS1 & TS2) and cams (TC1 & TC2). TS3 & TS4 can be added as feedback dry contacts.
 TS1 & TS2 : TS1 is for open and TS2 is for close. They torque switch the open and closed travel range by provides torque overload protection.
 TS3 & TS4 are optional. They allow external equipment to confirm that the valve has reached the torque limit value arbitrary.



- Dry contact sequence diagram (TS3 & TS4)

Symbol	Contact	Torque	
		Overload (Open)	Overload (Close)
TS4 (Dry Contact)	COM-NC	-----●-----	-----●-----
	COM-NO	-----●-----	-----●-----
TS3 (Dry Contact)	COM-NC	-----●-----	-----●-----
	COM-NO	-----●-----	-----●-----


- Solid line (—): Dry contact in conductive state.
- Dotted line (-----): Dry contact in non-conductive state.

6 Modulating Control Board Adjustment

6.1 OME-1, OME-A & OME-AM Modulating Control Board)

6.1.1 Surface Instruction

- ⓘ If the LED display is not operated for ten minutes, it will go out and return to the first level **99.9**. Please press any button to display it again. In local control mode, the LED display will return to remote control mode after it goes out.
- ⓘ The layout is based on 110 / 220 V AC.



Modulating Control

- Lamp Status


Lamp Code	Actuator Status
CL	Light on: Fully-Closed Flashing: Closing Direction
OP	Light on: Fully-Open Flashing: Opening Direction
ALM	Alerting Signal
REM	Remote Control Mode
LOC	Local Control Mode

- Analog Signal Connection Terminal Blocks

Terminal	Status
AO -	Analog signal output (-)
AO +	Analog signal output (+)
	N/A
AI -	Analog signal input (-)
AI +	Analog signal input (+)

6.1.2 Settings Menu

⚠ The Fieldbus Settings function is currently unavailable. It will be available in later version.




6.1.3 Position Percentage

➤ Standby

⚠ When an error occurs, the error code and the actuator's final position percentage will flash alternately (Refer to below warning message list).

- Range: 000 to 100
 - 0 % = 00.0, 100 % = 100
 - Example: 99.9% is displayed as 99.9.
- The LED display will show the current position of the actuator.



● Warning message list

Error Code	Warning Message
E17	Limit Switch Fault
E19	Digital Input Fault
E21	Input Signal Fault
E22	Output Signal Fault
E23	Flash Memory and Operating Status Fault
E27	Low Input Voltage
E30	Installation Error of Potentiometer
E31	Positioning Fault
E32	OPEN Potentiometer Fault
E33	CLOSE Potentiometer Fault
E34	Abnormal Current for Open Direction
E35	Abnormal Current for Closed Direction
E38	Signal Open Circuit

6.1.4 Auto Setup Auto

⚠ Be sure to reset OPEN and CLOSE position according to the following steps after recalibrating fully-open and fully-closed position.

- Auto setup for the fully-open and fully-closed positions.
- Setting Steps:
 - a. Press “DOWN” several times to get into Auto.
 - b. Press and hold “SET” around 3 sec to enter Auto Setup mode, Steps c to e will be executed automatically.
 - c. Auto run the actuator in CCW direction until the display shows 100% to reach the fully-open position.
 - d. Auto run the actuator in CW direction until the display shows 0% to reach the fully-closed position.
 - e. The setting is completed.

6.1.5 Local Control LoC

- The actuator could be directly controlled in the field.
- Setting Range: 0% to 100%.
- Setting Steps:
 - a. Press “DOWN” several times to get into LoC.
 - b. Press “SET” until LoC displays on to enter local control mode. The display will show the current position and the LoC lamp will light on.
 - c. Press “UP” and “DOWN” buttons to perform open and close settings. Press “UP” to run the actuator toward opening direction and press “DOWN” to run the actuator toward closing direction.
 - d. Press “MODE” to complete the local operation and return to the previous menu.

6.1.6 Parameter Setting PAR

6.1.6.1. Analog Signal Setting (Modulating Control) A 10

- ⚠ **Use a multimeter to measure the output signal in accordance with the selected signal type.**
- ⚠ **Be sure to complete the analog input /output signal type setting before setting the fully-closed / fully-open input / output signal.**

a. Analog Input Type A- 1

- Analog input signal type setting.
- Default Setting: 000
- Setting Steps:
 1. Press “DOWN” several times until PAR displays, then press “SET” once to enter parameter setting.
 2. Press “UP” or “DOWN” until A 10 displays, then press “SET” once to enter analog signal setting.
 3. Press “UP” or “DOWN” until A- 1 displays, then press “SET” once to enter analog input signal type setting.
 4. Press and hold “SET” around 3 sec until the indicator shows the parameter code and flashes.
 5. Press “UP” or “DOWN” to select desired parameter code according to the following table.

Parameter Code	Input Signal Type
000	4 - 20 mA
001	0 - 20 mA
002	1 - 5 V
003	0 - 5 V
004	2 - 10 V
005	0 - 10 V

6. Once selected, press “SET” once to complete analog input signal type setting.

b. Output Signal Type **A-o**

- Output signal type setting.
- Default Setting: **000**
- Setting Steps:
 1. Press “DOWN” several times until **PAR** displays, then press “SET” once to enter parameter setting.
 2. Press “UP” or “DOWN” until **A 10** displays, then press “SET” once to enter analog signal setting.
 3. Press “UP” or “DOWN” until **A-o** displays, then press “SET” once to enter output signal type setting.
 4. Press and hold “SET” around 3 sec until the display shows the parameter code and flashes.
 5. Press “UP” or “DOWN” to select desired parameter code according to the following table.

Parameter Code	Output Signal Type
000	4 - 20 mA
001	0 - 20 mA
002	1 - 5 V
003	0 - 5 V
004	2 - 10 V
005	0 - 10 V

6. Once selected, press “SET” once to complete output signal type setting.

- c. Input signal setting for fully-closed position 2r 1
- Set the input signal value for fully-closed position.
 - Setting Range: 000 to 4095.
 - The LED display is designed with hexadecimal format, so the value of 4095 is displayed as FFF.
 - Setting Steps:
 1. Press “DOWN” several times until PAR displays, then press “SET” once to enter parameter setting.
 2. Press “UP” or “DOWN” until R 10 displays, then press “SET” once to enter analog signal setting.
 3. Press “UP” or “DOWN” until 2r 1 displays, then press “SET” once to enter input signal setting for fully-closed position.
 4. Press and hold “SET” around 3 sec until the display shows the value and flashes.
 5. Use a signal generator to output a signal of 4 mA, 1 V, or 2 V based on the setting of R 1, then press "SET" once to complete the input signal setting of fully-closed position.

⚠ When the signal type of 0 - 20 mA, 0 - 5 V, or 0 - 10 V is selected, input the calibration signal value of 4 mA, 1 V, or 2 V to perform the setup.

Signal Type	Calibration Signal Value
4 - 20 mA	4 mA
0 - 20 mA	
1 - 5 V	1 V
0 - 5 V	
2 - 10 V	2 V
0 - 10 V	

- d. Input signal setting for fully-open position **FU**
- Set the input signal value for fully-open position.
 - Setting Range:000 to 4095 °
 - The LED indicator is displayed in hexadecimal format, so the value of 4095 is displayed as FFF.
 - Setting Steps:
 1. Press “DOWN” several times until **PAR** displays, then press “SET” once to enter parameter setting.
 2. Press “UP” or “DOWN” until **A 10** displays, then press “SET” once to enter analog signal setting.
 3. Press “UP” or “DOWN” until **FU** displays, then press “SET” to enter input signal setting for fully-open mode.
 4. Press and hold “SET” around 3 sec until the indicator shows the value and flashes.
 5. Use a signal generator to output a signal of 20 mA, 5 V, or 10 V based on the setting of **A- 1**, then press "SET" once to complete the input signal setting of fully-open position.

⚠ When the signal type of 0 - 20 mA, 0 - 5 V, or 0 - 10 V is selected, input the calibration signal value of 20 mA, 5 V, or 10 V to perform the setup.

Signal Type	Calibration Signal Value
4 - 20 mA	20 mA
0 - 20 mA	
1 - 5 V	5 V
0 - 5 V	
2 - 10 V	10 V
0 - 10 V	

- e. Output signal setting for fully-closed Position **2F0**
- Set the output signal value for fully-closed position.
 - Setting Range: 000 to 4095.
 - The LED display is designed with hexadecimal format, so the value of 4095 is displayed as FFF.
 - Setting Steps:
 1. Press “DOWN” several times until **PAR** displays, press “SET” once to enter parameter setting.
 2. Press “UP” or “DOWN” until **A 10** displays, then press “SET” once to enter analog signal setting.
 3. Press “UP” or “DOWN” until **2F0** displays, then press “SET” once to enter output signal setting for fully-closed mode.
 4. Press and hold “SET” around 3 sec until the display shows the value and flashes.
 5. Press “UP” or “DOWN” to adjust the value until the signal meter receives the value of 4 mA, 1 V or 2 V according to the output signal type of **A-0** setting. Then press “SET” once to complete the output signal setting for fully-closed position.
- ⚠ When the signal type of 0 - 20 mA, 0 - 5 V, or 0 - 10 V is selected, input the calibration signal value of 4 mA, 1 V, or 2 V to perform the setup.**

Signal Type	Calibration Signal Value
4 - 20 mA	4 mA
0 - 20 mA	
1 - 5 V	1 V
0 - 5 V	
2 - 10 V	2 V
0 - 10 V	


- f. Output signal setting for fully-open Position **FFo**
- Set the output signal value for fully- open position.
 - Setting Range:000 to 4095.
 - The LED display is designed with hexadecimal format, so the value of 4095 is displayed as FFF.
 - Setting Steps:
 1. Press “DOWN” several times until **PAR** displays, press “SET” once to enter parameter setting.
 2. Press “UP” or “DOWN” until **A 10** displays, then press “SET” once to enter analog signal setting.
 3. Press “UP or “DOWN” until **FFo** displays, then press “SET” enter output signal setting for fully-open mode.
 4. Press and hold “SET” around 3 sec, until the display shows the value and flashes.
 5. Press “UP” or “DOWN” to adjust the value until the signal meter receives the value of 20 mA, 5 V or 10 V according to the output signal type of **A-o** setting. Then press “SET” once to complete the output signal setting for fully-open position.

⚠ When the signal type of 0 - 20 mA, 0 - 5 V, or 0 - 10 V is selected, input the calibration signal value of 20 mA, 5 V, or 10 V to perform the setup.

Signal Type	Calibration Signal Value
4 - 20 mA	20 mA
0 - 20 mA	
1 - 5 V	5 V
0 - 5 V	
2 - 10 V	10 V
0 - 10 V	

g. Sensitivity Setting 5.5

- When the value of sensitivity (%) is lower, the resolution of the input signal will be higher, and relatively the dead band will be smaller. Excessive high resolution may cause the actuator to keep hunting and could not run to the desired position which will lead to the thermostat inside the motor to trip because of overheating, and finally the actuator will shut down. If this situation happens, it is suggested to adjust the sensitivity setting.
- Setting Range: 0.1 % to 5.0 %.
 - When set to 0.1 %, it means that the allowable tolerance is $\pm 0.1\%$, which is the highest sensitivity.
 - When set to 5.0 %, it means that the allowable tolerance is $\pm 5\%$, which is the lowest sensitivity.
 - For example, if the sensitivity switch is set to 1% and the target position is 50 %, the valid travel range will be from 49 % to 51 % as shown in the figure below.



- Default Setting:
 - OM-1, OM-A, OM-AM : 0.7 %
- Setting Steps:
 1. Press “DOWN” several times until PAR displays, then press “SET” once to enter parameter setting.
 2. Press “UP” or “DOWN” until R 10 displays, then press “SET” once to enter analog signal setting.
 3. Press “UP” or “DOWN” until 5.5 displays, then press “SET” once to enter sensitivity setting.
 4. Press and hold “SET” around 3 sec until the display shows the value and flashes.
 5. Press "UP" or "DOWN" to adjust the sensitivity switch setting.
 6. Press "SET" to complete the sensitivity switch setting.

h. Signal Open Circuit Action AL 1

- Action mode when the input signal fails or communication protocol timeout.

⚠ The function only available for the A- 1 set at 4 - 20 mA, 1 - 5 V or 2 - 10 V.

- Setting Range: 000 to 002

Parameter Code	Instruction
000	Stay at the last position when input signal fails or communication protocol timeout.
001	Run to the fully-open position when input signal fails or communication protocol timeout.
002	Run to the fully-closed position when input signal fails or communication protocol timeout.

- Default Setting: 002

- Setting Range:

1. Press “DOWN” several times until PAR displays, press “SET” once to enter parameter setting.
2. Press “UP” or “DOWN” until A 10 displays, then press “SET” once to enter signal setting.
3. Press “UP” or “DOWN” until AL 1 displays, then press “SET” once to enter signal open circuit action mode.
4. Press and hold “SET” around 3 sec until the display shows the value and flashes.
5. Press “UP” or “DOWN” to adjust the value.
6. Press "SET" to complete the signal open circuit action setting.

⚠ When set to 000 or 001, if a signal open circuit occurs, the actuator will operate to close direction for 1 second before executing the setting function.

6.1.6.2. Other oEH

a. Close Direction Setting d r

- Setting the CLOSE direction of output shaft, either CW or CCW.
- Setting Range:
 - 000: CW.
 - 001: CCW.
- Default Setting: 000
- Setting Steps:
 1. Press “DOWN” several times until PAR displays, press “SET” once to enter parameter setting.
 2. Press “UP” or “DOWN” until oEH displays, then press “SET” once.
 3. Press “UP” or “DOWN” until d r displays, then press “SET” once.
 4. Press and hold “SET” around 3 sec until the display shows the value and flashes.
 5. Press “UP” or “DOWN” to select 000 or 001.
 6. Press “SET” to complete the close direction setting.

b. Time Delay Setting SPd

- Time delay controller enables the running time to be delayed from a standard to required time per system requirements.
- Setting Range: 0 to 999.
- Default Setting: 000
- Setting Steps:
 1. Press “DOWN” several times until PAR displays, press “SET” once to enter parameter setting.
 2. Press “UP” or “DOWN” until oEH displays, then press “SET” once.
 3. Press “UP” or “DOWN” until SPd displays, then press “SET” once.
 4. Press and hold “SET” around 3 sec until the display shows the value and flashes.
 5. Press “UP” or “DOWN” to choose the seconds.
 - ⚠ **If the selected setting is less than the rated running time, the actuator will operate based on the rated running time as the minimum running duration.**
 6. Press “SET” to complete the time delay setting.

c. Input mode setting **500**

⚠ Be sure to reset OPEN and CLOSE position according to **AW0 setting after recalibrating fully-open and fully-closed position or any signal type setting.**

- Setting the valve control mode.
- Setting Range:
 - **000** : Under development
 - **001** : Modulating control.
 - **002** : Under development
- Default Setting: **001**
- Setting Steps:
 1. Press “DOWN” several times until **PAR** displays, then press “SET” once to enter signal setting mode.
 2. Press “UP” and “DOWN” until **001** displays, then press “SET” once.
 3. Press “UP” and “DOWN” until **500** displays, then press “SET” once.
 4. Press and hold “SET” around 3 sec until the display shows the value and flashes.
 5. Press “UP” or “DOWN” to select **001**.

Parameter Code	Input Mode
000	Under development
001	Modulating
002	Under development

6. Press “SET” to complete the input mode setting.

d. Motor Over-current (Real Time) CL A


- When the motor current value exceeds the set value, the motor will immediately stop and an error code will be displayed.

- Setting range: 0 to 9.99A

- Default Setting: 1.20

- Setting Steps:

1. Press “DOWN” several times until P A r displays, press “SET” once to enter parameter setting.
2. Press “UP” or “DOWN” until 0 2 H displays, then press “SET” once.
3. Press “UP” or “DOWN” until CL A displays, then press “SET” once.
4. Press and hold “SET” around 3 sec until the display shows the value and flashes.
5. Press “UP” or “DOWN” to set desired current value.
6. Press "SET" to complete the motor over-current (real time) setting.



e. Motor Over-current (Delay) CL U


- When the motor current exceeds the set value and remains for a period of time (motor over-current delay time), the motor will immediately stop and an error code will be displayed.

- Setting Range: 0 to 9.99A.

- Default Setting: 1.10

- Setting Steps:

1. Press “DOWN” several times until P A r displays, press “SET” once to enter parameter setting.
2. Press “UP” or “DOWN” until 0 2 H displays, then press “SET” once.
3. Press “UP” or “DOWN” until CL U displays, then press “SET” once.
4. Press and hold “SET” around 3 sec until the display shows the value and flashes.
5. Press “UP” or “DOWN” to set desired current value.
6. Press “SET” to complete the motor over-current (delay) setting.



f. Delay Time Setting for Motor Over-current CLE


- The delay time for sending an alarm when motor over-current is detected.
- Setting range: 0.01 to 9.99 sec.
- Default setting: 0.50
- Setting steps:
 1. Press “DOWN” several time until PAR displays, press “SET” once to enter parameter setting.
 2. Press “UP” or “DOWN” until pEtH displays, then press “SET” once.
 3. Press “UP” or “DOWN” until CLE displays, then press “SET” once.
 4. Press and hold “SET” around 3 sec until the display shows the value and flashes.
 5. Press “UP” or “DOWN” to set delay time.
 6. Press “SET” once to complete the delay time setting for motor over-current.

g. Firmware UER


- Display the current firmware version.
- Checking Steps:
 1. Press “DOWN” several times until PAR displays, then press “SET” once to enter parameter setting.
 2. Press “UP” or “DOWN” until pEtH displays, then press “SET” once.
 3. Press “UP” or “DOWN” until UER displays, then press “SET” to show the current firmware version.

h. Restore Default Setting rSE











- 000: The current setting value.
- 001: All parameters are restored to the default settings.
- Setting Steps:
 1. Press “DOWN” several times until PAR displays, then press “SET” once to enter parameter setting.
 2. Press “UP” or “DOWN” until 0EH displays, then press “SET” once.
 3. Press “UP” or “DOWN” until rSE displays.
 4. Press and hold “SET” around 3 sec until the display shows the value and flashes.
 5. Press “SET” once to show the default settings.
 6. Press “UP” to select 001.
 7. Press “SET” once to restore default setting.

 **Press “MODE” to return to the previous level if restore default setting is not required.**

6.1.7 Warning Messages (OME-1, OME-A & OME-AM)



- Press “UP” or “DOWN” to switch the numbers from 0 to 9.
- Press and hold “SET” to clean all the error data.
- Press “MODE” to return to return to the first level
- A maximum of 10 records can be recorded. Number 9 is the latest data and number 0 is the oldest data.
- The first digit shows the number of records, and the second and third one show the error code.
- The latest data is listed at the top and the oldest data at the bottom.

Error Code	Warning Message	Solution
	Limit Position Fault	Refer to 4.4.2 (P.18 to P.23) for adjustment steps setting.
	Digital Input Fault	Avoid inputting the “ON” digital signal for both open and closed control at the same time.
	Input Signal Fault	Please set the correct input signal type.
	Output Signal Fault	Please refer to the wiring diagram to confirm whether the input signal is connected correctly. (“ AO-”to “ AO+”).
	Flash Memory and Operating Status Fault	Replace a new modulating board.
	Low Input Voltage	1. Confirm the supply power. 2. Replace a new power board.
	Installation Error of Potentiometer	Contact the seller.
	Positioning Fault	Refer to 6.1.6.1 g (P.35) for sensitivity setting.
	OPEN Potentiometer Fault.	Confirm that if the torque is overloaded or the motor is locked. If this problem cannot be solved, please contact the seller.
	CLOSE Potentiometer Fault.	Confirm whether the torque is overloaded or the motor is locked. If the issue cannot be resolved, please contact the seller.


【 OME Series 】 Explosion-proof Quarter-turn Valve Actuator

34	Abnormal Current for Open Direction	Operate the handwheel to confirm if the valve is stuck by foreign objects.
35	Abnormal Current for Closed Direction	Operate the handwheel to confirm if the valve is stuck by foreign objects.
38	Signal Open Circuit	Confirm whether the input signal is connected.


6.2 Modulating Control Board (OME-2 to OME-8)

6.2.1 Surface

The layout is based on 110 / 220 V AC.




6.2.2 Programming




6.2.3 Dip Switch Setting (SW1)

The Dip Switch SW1 is a combination of 8 switches and equally divided in two rows. It is utilized to select signal type of input as well as output and fail positioning when the signal input fails. The sliders can be placed at either ON (upper) or OFF (lower) state position. Factory settings are switches 1, 4, 8 at ON state and switches 2, 3, 5, 6, 7 at OFF state.



	1	2	3	4	5	6	7	8
Factory Setting	ON	OFF	OFF	ON	OFF	OFF	OFF	ON
4 - 20 mA input	ON	OFF						
1 - 5 V input	OFF	OFF						
2 - 10 V input	OFF	ON						
4 - 20 mA output			OFF	ON	OFF			
2 - 10 V output			ON	OFF	ON			
Close direction setting: CW						OFF		
Close direction setting: CCW						ON		
When signal input failed, driving valve to fully-open							ON	OFF
When signal input failed, driving valve to fully-closed							OFF	ON
When signal input failed, valve stays at the last position							ON	ON
							OFF	OFF


a. Input signal setting (Switches 1 - 2)



Input Signal	State of Switch
4 - 20 mA	1 at ON, 2 at OFF
1 - 5 V	1 at OFF, 2 at OFF
2 - 10 V	1 at OFF, 2 at ON

【 OME Series 】 Explosion-proof Quarter-turn Valve Actuator

b. Output signal setting (Switches 3 - 5)






- Output signal can be fine-tuned by VR2.
- When resetting the Output Signal, be sure to fine-tune VR2 to match the setting either 2 - 10 V or 4 - 20 mA.

Output Signal	State of Switch
4 - 20 mA	3 at OFF, 4 at ON, 5 at OFF
2 - 10 V	3 at ON, 4 at OFF, 5 at ON

c. Close direction setting (switch 6)

- When S6 is set to OFF, the close direction is CW (clockwise).
 - When S6 is set to ON, the close direction is CCW (counterclockwise).
- ⚠ The input signal type is set by switches 1 and 2. And switch 6 is used to set the corresponding relationship between value of input signal and operation direction of actuator as shown in the figure below, e.g., 4 - 20 mA input signal.**
- ⚠ The operating direction of the actuator has been set and calibrated at the factory. Be sure to change the direction of the position indicator if different operating direction is required.**



When S6 is set to **OFF**



Position Indicator (Fully-Open → Fully-Closed)	Operating Position	Input Signal	LED	Output Signal
CW	Fully-Closed	1 V, 2 V, 4 mA	LD1 ON	2 V, 4 mA
	Fully-Open	5 V, 10 V, 20 mA	LD2 ON	10 V, 20 mA

【 OME Series 】 Explosion-proof Quarter-turn Valve Actuator

When S6 is set to **ON**



Position Indicator (Fully-Open→Fully-Closed)	Operating Position	Input Signal	LED	Output Signal
CCW	Fully-Closed	1 V, 2 V, 4 mA	LD1 ON	2 V, 4 mA
	Fully-Open	5 V, 10 V, 20 mA	LD2 ON	10 V, 20 mA

d. Failed position setting while the input signal failed. (switches 7 and 8)

- When a low signal value is received, the actuator operates toward fully-open position and when a high signal value is received, the actuator operates toward fully-open position.

Input Signal	Fully-Open	Fully-Closed
4 - 20 mA	4 mA	20 mA
1 - 5 V	1 V	5 V
2 - 10 V	2 V	10 V


- The selection of the fail position while the input signal failed, please follow table below:

Signal Failed Position	State of Switch
Fully-Open	7 at ON, 8 at OFF
Fully-Closed	7 at OFF, 8 at ON
The Last Position	7 at ON, 8 at ON 7 at OFF, 8 at OFF

6.2.4 Sensitivity Switch Setting (SW2)


When the value of sensitivity (%) is lower, the resolution of the input signal will be higher, and relatively the dead band will be smaller. Excessive high resolution may cause the actuator to keep hunting and could not run to the desired position which will lead to the thermostat inside the motor to trip because of overheating, and finally the actuator will shut down. If this situation happens, it is suggested to adjust the sensitivity setting.

a. Setting



Setting Value	1	2	3	4	5	6	7	8	9	0
Sensitivity (%)	0.25	0.5	0.75	1	1.25	1.5	1.75	2	2.25	2.5

- When switched to “1”: The Highest Sensitivity.
- When switched to “0”: The Lowest Sensitivity.
- For example: When the sensitivity switch is set to “3” (0.75%) and the target position is 50%, the valid travel range will be from 49.25% to 50.75% ($50\% \pm 0.75\%$) as shown in the figure below.




b. Original Factory Setting

- OME-2 to OME-8: 3



6.2.5 Signal Setting for Open and Close Position

- ⚠ **These settings are set and calibrated at the factory. Be sure to reset the Signal Setting for Open and Close Position when recalibrating TC1 and TC2 for fully-open and fully-closed position or other signal types are required.**
- ⚠ **Use a multimeter to measure the output signal in accordance with the selected signal type.**
 - Using UP, DN, MODE, SET buttons to set the open and close position.



Lamp	Status	Lamp	Status
LD1	Fully-closed	LD6	Motor thermal protector activated
LD2	Fully-open	LD7	Output signal short circuit
LD3	Power	LD8	Overcurrent in motor
LD4	Abnormal input voltage	LD9	Local setting mode
LD5	Wrong input signal		

Press and hold "SET" button for 2 seconds until LD 9 lights to enter local setting mode.

⚠ **Please adjust the signal setting for fully-open position first, then adjust the signal setting for fully-closed position.**

- **Signal setting for Fully-OPEN position**
 - a. Press and hold "UP" button to operate the actuator to open until it has reached fully-open position and LD2 lights and then input a signal 5 V or 10 V or 20 mA.
 - b. Press "MODE" button for 2 seconds until LD2 flashes to complete the setting of fully-open position.
- **Signal setting for Fully-CLOSED position**
 - a. Press and hold "DN" button to operate the actuator to close until it has reached fully-closed position and LD1 lights and then input a signal 1 V or 2 V or 4 mA.
 - b. Press "MODE" button for 2 seconds until LD1 flashes to complete the setting of fully-closed position.

⚠ **See below description for VR2 adjustment:**

- VR2
- ↻ Clockwise: decreasing signal value.
 - ↺ Counter-clockwise: increasing signal value.

After completing the above settings, press "SET" button to quit local setting.

6.2.6 Troubleshooting of Modulating Controller (OME-2 to OME-8)

⚠ In case LD3 does not light or any of LD4 to LD9 lights when the actuator is motorized, please refer to steps below for basic troubleshooting.

⚠ Please do the troubleshooting when LD4 to LD8 lights, and then restart the power to turn the lights off.

Status of LEDs	Possible problems	Solution
LD3 does not go on	<ul style="list-style-type: none"> a. No power supplied. b. Incorrect connection of the lines #8, #9 of potentiometer. c. Modulating controller failed. 	<ul style="list-style-type: none"> a. Check the power supply as well as wires connected to terminals #4 & #5, please refer to 6.2 (P.44) b. Verify the actuator is wired properly as per wiring diagram. c. Send back to factory for inspection.
LD4 goes on (for 24V units)	The voltage is under 20.4V.	Verify that the input voltage is within the allowable voltage deviation.
LD5 goes on	<ul style="list-style-type: none"> a. An incorrect signal type inputted. For example, preset with 2-10 V input but input 4-20 mA. b. Input a voltage exceeding the rated. For example, preset with 2-10 V input but input 13.5V. c. An incorrect signal type inputted. For example, preset with 4 - 20 mA input but input 2 - 10V. In this case, the actuator still works in 2 - 7V. When the signal is over 7.2 V, the LD5 lights. 	Verify if the switch 1 is set in accordance with the type of input signal. Please refer to 6.2.3 (P.45 - P.47).
LD6 goes on	Motor thermal protector started.	<ul style="list-style-type: none"> a. The duty cycle exceeded the rated, please refer to 3.5 (P.10). b. The contact of motor thermal protector (MOT) disconnected.

【 OME Series 】 Explosion-proof Quarter-turn Valve Actuator

Status of LEDs	Possible problems	Solution
LD7 goes on	<ul style="list-style-type: none"> a. Signal output short circuits. b. Both DIP switch #3 and #4 are set at ON or OFF. 	<ul style="list-style-type: none"> a. Verify if the signal output with reversed polarity. The negative pole should be connected to terminal #11 and the positive pole should be connected to terminal #12. b. Reset the dip switches per actual output signal. Please refer to 6.2.3 (P.45 - P.47)
LD8 goes on	Motor over-current.	<ul style="list-style-type: none"> a. Duty cycle exceeded the rated, please refer to 3.6 (P.11) and reduce the duty rating. b. Check the load. c. Check if the motor rotor is locked (For example: Valve is stuck by foreign objects).
LD9 goes on	Local setting mode - Setting position for open & close.	After completing the settings, press “SET” button to quit.

7 Troubleshooting

Floating Control

Motor can not operate or overheats.

Possible problems	Solution
a. The limit switch for fully-closed does not trip.	a. Operate the actuator manually to fully-closed position and confirm if the limit switch trips.
b. Motor shaft or bearing were stuck.	b. Switch to manual operation mode and power on to see if the motor could not drive the gears, it means that the motor shaft or bearing is stuck and the motor needs to be replaced.
c. Power applied to terminals #3 and #4 simultaneously (Abnormal Wiring).	c. Follow the wiring diagram inside the cover to connect wires and make sure the wiring is correct.
d. Jammed pipe or stuck valve seat.	d. Check if any blockage or obstacle in pipe and remove.
e. The seating torque of valve increased due to oxidized seals and has resulted in a torque overload on actuator.	e. Manual operate to check if it can be operated, if not, replace the valve.

The actuator operates but the motor is hot.

Possible problems	Solution
a. The mechanical stop screws ran into the output drive gearing.	a. Reset the mechanical end stops and travel cams, please refer to 4.4.2 (P.18 - P.23).
b. A torque overload caused by the valve.	b. This situation occurs frequently after the valve has been operating for a period of time. It is suggested to replace with a new valve.
c. Wrong power supply.	c. Check the power supply.
d. Actuator operates too frequently and exceeded duty cycle rating.	d. Adjust the system bandwidth or reduce the frequency of operation, please refer to 3.6 (P.11).

To control two or more actuators, sometimes the actuator works abnormally and the motor is getting hot.

Possible problems	Solution
Parallel connection.	a. Install parallel board (Optional). b. Please contact your distributor to receive the wiring diagram for parallel connection.

【 OME Series 】 Explosion-proof Quarter-turn Valve Actuator

The valve cannot operate either electrical operation or manual operation.

Possible problems	Solution
a. The actuator was mounted to the valve improperly.	a. Please refer to 4.2 (P.15) valve installation instructions.
b. The set screw of the cam loosened and resulted in that the travel end positions misaligned.	b. Readjust the mechanical end stops and limit switches, please refer to 4.4.2 (P.18 - P.23).
c. The torque of valve is larger than the torque of actuator.	c. Replace with a new valve or a larger size actuator.
d. The actuator was mounted to the valve improperly.	d. Disassemble the actuator from the valve and reassemble them to verify that they are installed properly.

None of the LED indicators on the PCBA lit up after power is supplied.

Possible problems	Solution
a. Blown fuse.	a. Replace a new fuse.
b. PCBA failed.	b. Replace a new PCBA.
c. Wrong supply voltage.	c. Check the power supply.

The capacitor is faulty.

Possible problems	Solution
The ambient temperature is too high or too low.	The actuator should be installed within the rated ambient temperature range of -30 °C to +65 °C (-22 °F to + 149 °F).

Modulating Control

The LED indicators (LD4 - LD9) flash. (OME-2 to OME-8)

Solution

Please refer to 6.2.6 (P.50).

The LED indicators on the modulating board are normal, but the actuator cannot operate or can only operate in either the fully-open or fully-closed position.

Possible problems	Solution
The input signal with a reversed polarity, it means a signal failure.	Verify if the negative pole of signal input connected to terminal #6 and the positive pole connected to terminal #7.

Modulating control is not functioning.

Possible problems	Solution
a. The modulating board is faulty, and the actuator cannot operate or can only operate in one direction.	a. Replace a new modulating board
b. Input wrong signal type.	b. Check if the input signal is correct, please refer to 6.1.6.1 (P.29) or .6.2.3 (P.45 ~ P.47)
c. Modulating board failed and causes actuator cannot operate or only operate in a single direction.	c. Replace a new modulating board.

8 Warranty

Sun Yeh Electrical Ind. Co., Ltd warrants that for a period of twelve months from the date of manufacture it will either repair or replace, at its option, any of its products which prove to be defective in material or workmanship. This warranty does not cover damage resulting from causes such as abuse, misuse, modification or tampering by users. This warranty is extended only to the immediate purchaser of the Sun Yeh product and is not transferable. To obtain service under this warranty, the purchaser must first acquire a return authorization from Sun Yeh. Products must be returned to Sun Yeh under freight prepaid.

This warranty is in lieu of all other obligations, liabilities or expressed warranties. Any implied warranties, including any implied warranty of merchantability are hereby expressly excluded. In no event shall Sun Yeh be liable for special, incidental or consequential damages arising in connection with the use of its products, or for any delay in the performance of this warranty due to cause beyond its control.

9 Disposal

Please obey the local environment regulation for equipment scrapping.



SUN YEH ELECTRICAL IND. CO., LTD.

No.68, Ln. 854, Sec. 1, Shatian Rd., Dadu Dist.,
Taichung City 432, Taiwan
Tel: +886-4-26985666 Fax: +886-4-26983668
E-mail: service@sunyeh.com



www.sunyeh.com