

Multi-turn Electric Valve Actuators



OPERATION MANUAL







SUN YEH ELECTRICAL IND. CO., LTD.

SY04-C004C-EN

Contents

1.1 Safety Instructions 2 1.2 Installation, Storage, Transport 2 2 Product Overview 3 2.1 Features 3 3 Product Mechanical Data 4 3.1 Parts Identification 4 3.1 Parts Identification 5 3.3 Technical Data 6 3.4 External Gear Box 6 4 Storage, Transport and Packaging 7 4.1 Receiving / Inspection 7 4.2 Storage 7 4.3 Transport 7 5 Mounting. 9 5.1 Preparing Actuator Drive Bush. 9 5.2 Mounting Actuator with Valve. 10 5.3 Mounting Dast-proof Stem Protection Sleeve 15 6 Electrical Connection. 16 6.1 Terminal Block Layout 16 6.2 Removing Terminal Cover 17 6.3 Electrical Connection - Cable Connection 18 7 Manual Operation 21 <t< th=""><th>1</th><th>Genera</th><th>al Information</th><th>2</th></t<>	1	Genera	al Information	2
1.2 Installation, Storage, Transport. 2 2 Product Overview		1.1	Safety Instructions	2
2 Product Overview 3 2.1 Features 3 3 Product Mechanical Data 4 3.1 Parts Identification 4 3.2 Nameplate Instruction 5 3.3 Technical Data 6 3.4 External Gear Box 6 4 Storage, Transport and Packaging 7 4.1 Receiving / Inspection 7 4.2 Storage 7 4.3 Transport 7 5 Mounting 9 5.1 Preparing Actuator Drive Bush. 9 5.2 Mounting Actuator with Valve 10 5.3 Mounting Actuator with Valve 12 5.4 Mounting Cutuator with Valve 12 5.4 Mounting Cutuator with Gear box 14 5.5 Mounting Cutuator with Gear box 14 5.6 Electrical Connection 16 6.1 Terminal Block Layout 16 6.2 Removing Terminal Cover 17 6.3 Electrical Connection - Cable Connection 18		1.2	Installation, Storage, Transport	2
2.1 Features. 3 3 Product Mechanical Data. 4 3.1 Parts Identification. 4 3.2 Nameplate Instruction. 5 3.3 Technical Data 6 3.4 External Gear Box 6 4.1 Receiving / Inspection 7 4.1 Receiving / Inspection 7 4.2 Storage 77 4.3 Transport 7 5 Mounting 9 5.1 Preparing Actuator Drive Bush. 9 5.2 Mounting Actuator with Valve 10 5.3 Mounting Dust-proof Stem Protection Sleeve 15 6 Electrical Connection 16 6.1 Terminal Block Layout 16 6.2 Removing Terminal Cover. 17 6.3 Electrical Connection - Cable Connection 18 7 Manual Operation Steps 19 8 Manual Operation Steps 19 8.1 Introduction 27 8.3 Operation 21 8.4 <td>2</td> <td>Produc</td> <td>et Overview</td> <td>3</td>	2	Produc	et Overview	3
3 Product Mechanical Data. 4 3.1 Parts Identification 4 3.2 Nameplate Instruction. 5 3.3 Technical Data 6 3.4 External Gear Box 6 4 Storage, Transport and Packaging 7 4.1 Receiving / Inspection 7 4.2 Storage 77 4.3 Transport 7 5 Mounting 9 5.1 Preparing Actuator Drive Bush. 9 5.2 Mounting Actuator with Valve 10 5.3 Mount Gear Box with Valve 10 5.4 Mounting Actuator with Gaer box 14 5.5 Mounting Actuator with Gaer box 14 5.4 Mounting Actuator with Gear box 16 6 Electrical Connection. 16 6.1 Terminal Block Layout 16 6.2 Removing Terminal Cover. 17 6.3 Electrical Operation Steps 19 7.1 Manual Operation Steps 19 7.1 Manual Operation Steps <t< td=""><td></td><td>2.1</td><td>Features</td><td>3</td></t<>		2.1	Features	3
3.1 Parts Identification 4 3.2 Nameplate Instruction 5 3.3 Technical Data 6 3.4 External Gear Box 6 4 Storage, Transport and Packaging 7 4.1 Receiving / Inspection 7 4.2 Storage 7 4.3 Transport 7 5 Mounting 9 5.1 Preparing Actuator Drive Bush. 9 5.2 Mounting Actuator with Valve 10 5.3 Mount Gear Box with Valve 10 5.3 Mounting Actuator with Gear box 14 5.5 Mounting Dust-proof Stem Protection Sleeve 15 6 Electrical Connection 16 6.1 Terminal Block Layout 16 6.2 Removing Terminal Cover 17 6.3 Electrical Onnection - Cable Connection 18 7 Manual Operation Steps 19 7.1 Manual Operation 21 8.1 Introduction 21 8.2 User Management 27	3	Produc	et Mechanical Data	4
3.2 Nameplate Instruction .5 3.3 Technical Data .6 3.4 External Gear Box .6 4 Storage, Transport and Packaging .7 4.1 Receiving / Inspection .7 4.2 Storage .7 4.3 Transport .7 5 Mounting .9 5.1 Preparing Actuator Drive Bush .9 5.2 Mounting Actuator with Valve .10 5.3 Mounting Actuator with Valve .12 5.4 Mounting Actuator with Gear box .14 5.5 Mounting Dust-proof Stem Protection Sleeve .15 6 Electrical Connection .16 6.1 Terminal Block Layout .16 6.2 Removing Terminal Cover .17 6.3 Electrical Connection - Cable Connection .18 7 Manual Operation .21 8.1 Introduction .21 8.2 User Management .27 8.3 Operation .21 8.4 Status .32		3.1	Parts Identification	4
3.3 Technical Data 6 3.4 External Gear Box 6 4 Storage, Transport and Packaging 7 4.1 Receiving / Inspection 7 4.2 Storage 7 4.3 Transport 7 5 Mounting 9 5.1 Preparing Actuator Drive Bush 9 5.2 Mounting Actuator with Valve 10 5.3 Mount Gear Box with Valve 12 5.4 Mounting Actuator with Gear box 14 5.5 Mounting Actuator with Gear box 14 5.6 Electrical Connection 16 6.1 Terminal Block Layout 16 6.2 Removing Terminal Cover 17 6.3 Electrical Connection - Cable Connection 18 7.1 Manual Operation 19 7.1 Manual Operation 21 8.1 Introduction 21 8.2 User Management 27 8.3 Operation 29 8.4 Status 32 8.5		3.2	Nameplate Instruction	5
3.4 External Gear Box 6 4 Storage, Transport and Packaging 7 4.1 Receiving / Inspection 7 4.2 Storage 7 4.3 Transport 7 5 Mounting 9 5.1 Preparing Actuator Drive Bush 9 5.2 Mounting Actuator with Valve 10 5.3 Mount Gear Box with Valve 12 5.4 Mounting Actuator with Gear box 14 5.5 Mounting Dust-proof Stem Protection Sleeve 15 6 Electrical Connection 16 6.1 Terminal Block Layout 16 6.2 Removing Terminal Cover 17 6.3 Electrical Connection - Cable Connection 18 7 Manual Operation 21 8.1 Introduction 21 8.2 User Management 27 8.3 Operation 29 8.4 Status 32 8.5 Control System Settings 37 8.6 Set Maintenance Due 40		3.3	Technical Data	6
4 Storage, Transport and Packaging		3.4	External Gear Box	6
4.1 Receiving / Inspection 7 4.2 Storage 7 4.3 Transport 7 5 Mounting 9 5.1 Preparing Actuator Drive Bush 9 5.2 Mounting Actuator with Valve 10 5.3 Mount Gear Box with Valve 12 5.4 Mounting Actuator with Gear box 14 5.5 Mounting Dust-proof Stem Protection Sleeve 15 6 Electrical Connection 16 6.1 Terminal Block Layout 16 6.2 Removing Terminal Cover 17 6.3 Electrical Connection - Cable Connection 18 7 Manual Operation Steps 19 8 Electrical Operation Steps 19 8.1 Introduction 21 8.2 User Management 27 8.3 Operation 29 8.4 Status 32 8.5 Control System Settings 37 8.6 Set Maintenance Due 40 8.7 Parameter Setting 42	4	Storag	e, Transport and Packaging	7
4.2 Storage 7 4.3 Transport 7 5 Mounting. 9 5.1 Preparing Actuator Drive Bush. 9 5.2 Mounting Actuator with Valve. 10 5.3 Mount Gear Box with Valve 12 5.4 Mounting Actuator with Gear box. 14 5.5 Mounting Dust-proof Stem Protection Sleeve 15 6 Electrical Connection. 16 6.1 Terminal Block Layout 16 6.2 Removing Terminal Cover. 17 6.3 Electrical Connection - Cable Connection 18 7 Manual Operation 19 7.1 Manual Operation 21 8.1 Introduction. 21 8.2 User Management 27 8.3 Operation 29 8.4 Status. 32 8.5 Control System Settings 37 8.6 Set Maintenance Due 40 8.7 Parameter Setting 42 8.8 System Control Setting 56		4.1	Receiving / Inspection	7
4.3 Transport 7 5 Mounting 9 5.1 Preparing Actuator Drive Bush 9 5.2 Mounting Actuator with Valve 10 5.3 Mount Gear Box with Valve 12 5.4 Mounting Actuator with Gear box 14 5.5 Mounting Dust-proof Stem Protection Sleeve 15 6 Electrical Connection 16 6.1 Terminal Block Layout 16 6.2 Removing Terminal Cover 17 6.3 Electrical Connection - Cable Connection 18 7 Manual Operation 19 7.1 Manual Operation Steps 19 8 Electrical Operation Steps 19 8.1 Introduction 21 8.2 User Management 27 8.3 Operation 29 8.4 Status 32 8.5 Control System Settings 37 8.6 Set Maintenance Due 40 8.7 Parameter Setting 56 8.9 Fieldbus Setting 56		4.2	Storage	7
5 Mounting. .9 5.1 Preparing Actuator Drive Bush. .9 5.2 Mounting Actuator with Valve. .10 5.3 Mount Gear Box with Valve .12 5.4 Mounting Actuator with Gear box. .12 5.4 Mounting Dust-proof Stem Protection Sleeve. .15 6 Electrical Connection. .16 6.1 Terminal Block Layout. .16 6.2 Removing Terminal Cover. .17 6.3 Electrical Connection - Cable Connection .18 7 Manual Operation .19 7.1 Manual Operation Steps .19 8 Electrical Operation .21 8.1 Introduction .21 8.2 User Management .27 8.3 Operation .21 8.4 Status .32 8.5 Control System Settings .37 8.6 Set Maintenance Due .40 8.7 Parameter Setting .42 8.8 System Control Setting .62 9 Servicing and Main		4.3	Transport	7
5.1 Preparing Actuator Drive Bush	5	Mount	ing	9
5.2 Mounting Actuator with Valve 10 5.3 Mount Gear Box with Valve 12 5.4 Mounting Actuator with Gear box. 14 5.5 Mounting Dust-proof Stem Protection Sleeve. 15 6 Electrical Connection. 16 6.1 Terminal Block Layout. 16 6.2 Removing Terminal Cover. 17 6.3 Electrical Connection - Cable Connection 18 7 Manual Operation 19 7.1 Manual Operation Steps 19 8 Electrical Operation 21 8.1 Introduction. 21 8.2 User Management. 27 8.3 Operation 29 8.4 Status. 32 8.5 Control System Settings 37 8.6 Set Maintenance Due 40 8.7 Parameter Setting 42 8.8 System Control Setting 56 8.9 Fieldbus Setting 56 9 Servicing and Maintenance 64 9.1 Battery Maintenance		5.1	Preparing Actuator Drive Bush	9
5.3 Mount Gear Box with Valve 12 5.4 Mounting Actuator with Gear box 14 5.5 Mounting Dust-proof Stem Protection Sleeve 15 6 Electrical Connection 16 6.1 Terminal Block Layout 16 6.2 Removing Terminal Cover 17 6.3 Electrical Connection - Cable Connection 18 7 Manual Operation 19 7.1 Manual Operation Steps 19 8 Electrical Operation 21 8.1 Introduction 21 8.2 User Management 27 8.3 Operation 29 8.4 Status 32 8.5 Control System Settings 37 8.6 Set Maintenance Due 40 8.7 Parameter Setting 42 8.8 System Control Setting 56 9 Servicing and Maintenance 64 9.1 Battery Maintenance 64 9.2 Oil Replacement 65 9.3 Maintenance 66		5.2	Mounting Actuator with Valve	10
5.4 Mounting Actuator with Gear box 14 5.5 Mounting Dust-proof Stem Protection Sleeve 15 6 Electrical Connection 16 6.1 Terminal Block Layout 16 6.2 Removing Terminal Cover 17 6.3 Electrical Connection - Cable Connection 18 7 Manual Operation 19 7.1 Manual Operation Steps 19 8 Electrical Operation 21 8.1 Introduction 21 8.2 User Management 27 8.3 Operation 29 8.4 Status 32 8.5 Control System Settings 37 8.6 Set Maintenance Due 40 8.7 Parameter Setting 42 8.8 System Control Setting 56 8.9 Fieldbus Setting 62 9 Servicing and Maintenance 64 9.1 Battery Maintenance 64 9.2 Oil Replacement 65 9.3 Maintenance 66		5.3	Mount Gear Box with Valve	.12
5.5 Mounting Dust-proof Stem Protection Sleeve 15 6 Electrical Connection 16 6.1 Terminal Block Layout 16 6.2 Removing Terminal Cover 17 6.3 Electrical Connection - Cable Connection 18 7 Manual Operation 19 7.1 Manual Operation Steps 19 8 Electrical Operation 21 8.1 Introduction 21 8.2 User Management 27 8.3 Operation 29 8.4 Status 32 8.5 Control System Settings 37 8.6 Set Maintenance Due 40 8.7 Parameter Setting 42 8.8 System Control Setting 56 8.9 Fieldbus Setting 62 9 Servicing and Maintenance 64 9.1 Battery Maintenance 64 9.2 Oil Replacement 65 9.3 Maintenance 65 9.3 Maintenance 66 9.4		5.4	Mounting Actuator with Gear box	14
6 Electrical Connection 16 6.1 Terminal Block Layout 16 6.2 Removing Terminal Cover 17 6.3 Electrical Connection - Cable Connection 18 7 Manual Operation 19 7.1 Manual Operation Steps 19 8 Electrical Operation 21 8.1 Introduction 21 8.2 User Management 27 8.3 Operation 29 8.4 Status 32 8.5 Control System Settings 37 8.6 Set Maintenance Due 40 8.7 Parameter Setting 42 8.8 System Control Setting 56 8.9 Fieldbus Setting 62 9 Servicing and Maintenance 64 9.1 Battery Maintenance 64 9.2 Oil Replacement 65 9.3 Maintenance 66 9.4 Operation Protection 66 9.4 Operation Protection 66 9.4 Operatio		5.5	Mounting Dust-proof Stem Protection Sleeve	15
6.1Terminal Block Layout166.2Removing Terminal Cover176.3Electrical Connection - Cable Connection187Manual Operation197.1Manual Operation Steps198Electrical Operation218.1Introduction218.2User Management278.3Operation298.4Status328.5Control System Settings378.6Set Maintenance Due408.7Parameter Setting428.8System Control Setting568.9Fieldbus Setting629Servicing and Maintenance649.1Battery Maintenance649.2Oil Replacement659.3Maintenance669.4Operation Protection6610Troubleshooting6711Warranty71	6	Electri	cal Connection	16
6.2Removing Terminal Cover176.3Electrical Connection - Cable Connection187Manual Operation197.1Manual Operation Steps198Electrical Operation218.1Introduction218.2User Management278.3Operation298.4Status328.5Control System Settings378.6Set Maintenance Due408.7Parameter Setting428.8System Control Setting568.9Fieldbus Setting629Servicing and Maintenance649.1Battery Maintenance649.2Oil Replacement659.3Maintenance669.4Operation Protection6610Troubleshooting6711Warranty71		6.1	Terminal Block Layout	16
6.3Electrical Connection - Cable Connection187Manual Operation197.1Manual Operation Steps198Electrical Operation218.1Introduction218.2User Management278.3Operation298.4Status328.5Control System Settings378.6Set Maintenance Due408.7Parameter Setting428.8System Control Setting568.9Fieldbus Setting629Servicing and Maintenance649.1Battery Maintenance649.2Oil Replacement659.3Maintenance669.4Operation Protection6610Troubleshooting6711Warranty71		6.2	Removing Terminal Cover	.17
7 Manual Operation 19 7.1 Manual Operation Steps 19 8 Electrical Operation 21 8.1 Introduction 21 8.2 User Management 27 8.3 Operation 29 8.4 Status 32 8.5 Control System Settings 37 8.6 Set Maintenance Due 40 8.7 Parameter Setting 42 8.8 System Control Setting 56 8.9 Fieldbus Setting 62 9 Servicing and Maintenance 64 9.1 Battery Maintenance 64 9.2 Oil Replacement 65 9.3 Maintenance 66 9.4 Operation Protection 66 10 Troubleshooting 67 11 Warranty 71		6.3	Electrical Connection - Cable Connection	18
7.1Manual Operation Steps198Electrical Operation218.1Introduction218.2User Management278.3Operation298.4Status328.5Control System Settings378.6Set Maintenance Due408.7Parameter Setting428.8System Control Setting568.9Fieldbus Setting629Servicing and Maintenance649.1Battery Maintenance649.2Oil Replacement659.3Maintenance669.4Operation Protection6610Troubleshooting6711Warranty71	7	Manua	l Operation	19
8 Electrical Operation 21 8.1 Introduction 21 8.2 User Management 27 8.3 Operation 29 8.4 Status 32 8.5 Control System Settings 37 8.6 Set Maintenance Due 40 8.7 Parameter Setting 42 8.8 System Control Setting 56 8.9 Fieldbus Setting 62 9 Servicing and Maintenance 64 9.1 Battery Maintenance 64 9.2 Oil Replacement 65 9.3 Maintenance 66 9.4 Operation Protection 66 10 Troubleshooting 67 11 Warranty 71		7.1	Manual Operation Steps	19
8.1Introduction218.2User Management278.3Operation298.4Status328.5Control System Settings378.6Set Maintenance Due408.7Parameter Setting428.8System Control Setting568.9Fieldbus Setting629Servicing and Maintenance649.1Battery Maintenance649.2Oil Replacement659.3Maintenance669.4Operation Protection6610Troubleshooting6711Warranty71	8	Electri	cal Operation	21
8.2User Management278.3Operation298.4Status328.5Control System Settings378.6Set Maintenance Due408.7Parameter Setting428.8System Control Setting568.9Fieldbus Setting629Servicing and Maintenance649.1Battery Maintenance649.2Oil Replacement659.3Maintenance669.4Operation Protection6610Troubleshooting6711Warranty71		8.1	Introduction	21
8.3Operation298.4Status328.5Control System Settings378.6Set Maintenance Due408.7Parameter Setting428.8System Control Setting568.9Fieldbus Setting629Servicing and Maintenance649.1Battery Maintenance649.2Oil Replacement659.3Maintenance669.4Operation Protection6610Troubleshooting6711Warranty71		8.2	User Management	.27
8.4Status328.5Control System Settings378.6Set Maintenance Due408.7Parameter Setting428.8System Control Setting568.9Fieldbus Setting629Servicing and Maintenance649.1Battery Maintenance649.2Oil Replacement659.3Maintenance669.4Operation Protection6610Troubleshooting6711Warranty71		8.3	Operation	.29
8.5Control System Settings.378.6Set Maintenance Due.408.7Parameter Setting.428.8System Control Setting.568.9Fieldbus Setting.629Servicing and Maintenance.649.1Battery Maintenance.649.2Oil Replacement.659.3Maintenance.669.4Operation Protection.6610Troubleshooting.6711Warranty.71		8.4	Status	.32
8.6Set Maintenance Due.408.7Parameter Setting.428.8System Control Setting.568.9Fieldbus Setting.629Servicing and Maintenance.649.1Battery Maintenance.649.2Oil Replacement.659.3Maintenance.669.4Operation Protection.6610Troubleshooting.6711Warranty.71		8.5	Control System Settings	.37
8.7Parameter Setting.428.8System Control Setting.568.9Fieldbus Setting.629Servicing and Maintenance.649.1Battery Maintenance.649.2Oil Replacement659.3Maintenance.669.4Operation Protection.6610Troubleshooting.6711Warranty.71		8.6	Set Maintenance Due	.40
8.8System Control Setting		8.7	Parameter Setting	.42
8.9Fieldbus Setting		8.8	System Control Setting	56
9Servicing and Maintenance		8.9	Fieldbus Setting	.62
9.1Battery Maintenance	9	Servic	ing and Maintenance	.64
9.2Oil Replacement		9.1	Battery Maintenance	.64
9.3Maintenance		9.2	Oil Replacement	.65
9.4Operation Protection6610Troubleshooting6711Warranty71		9.3	Maintenance	66
10 Troubleshooting		9.4	Operation Protection	.66
11 Warranty	10	Troubl	eshooting	.67
	11	Warrai	nty	71
12 Disposal	12	Dispos	sal	71

1 General Information

Failure to follow safety instructions may cause serious injury, equipment damage, or voided warranty.

1.1 Safety Instructions

- Installation, maintenance and repair works must be performed by trained personnel.
- The Handling shall follow the safety and warning instruction contained in this manual.
- The user should read and follow instructions contained in this operation manual. Failure to do this may result in damages and void warranty. Sun Yeh will not be liable for damages due to operator negligence or misuse.
- Local health and safety regulation shall be complied with.
- In a few cases, the surface temperature may exceed 60°C (140 °F). Please check the surface temperature before operation, using an appropriate thermometer and wearing protective gloves before operation.

1.2 Installation, Storage, Transport

- Please read operation manual and wiring diagram carefully before installation.
- Perform all basic settings including stroke limitation for open and close direction prior to operation.
- Verify the power supply's voltage is in accordance with the data on nameplate to prevent short circuit or electrical/electronic parts damage caused by incorrect power input.
- Turn power off before wiring or maintenance.
- Connect the ground wire to PE point inside the electric actuator.
- To avoid functional failure caused by static, do not touch any components on the PCBA with metal tools or bare hands.
- Use proper techniques when installing conduit and properly seal the connection to prevent vapor condensation from entering the unit.
- Actuator should be installed in an upright or horizontal position. Do not mount upside down or below a horizontal position.
- These units are not designed to operate in vacuum spaces or where an explosive atmosphere exists.
- Periodically inspect actuator enclosure to prevent dust from accumulating.

2 Product Overview

Sun Yeh M series multi-turn electric actuators are designed to provide output torque from 41 Nm to 100 Nm (363 in·lb to 885 in·lb) and output speed from 15 rpm to 120 rpm which fit with various types of valves. After combining with a gear box, the maximum output torque increases.

It comes standard with backlit LCD display and reed switches to make operation easily under different light conditions.

The manual override is equipped to enable the automatic operating mode switched to manual operation easily and stably, no matter under operation or during power outages.

2.1 Features

- Five speeds can be chosen. The output torque remains constant when output speed changes.
- High efficiency BLDC motor technology allows output torque and speed adjustable in both directions.
- Manual / electrical control can be switched via a lever. When the motor is electrically activated, for safety reason, the handwheel will not rotate to prevent personnel injury.
- Torque overload protection at each end of stroke.
- Double-sealed and IP68 (8 m, 120 hrs) enclosure protection.
- Patent obtained in UK, USA, Taiwan, China, Japan, and Germany.
- Setting, monitoring, and diagnosing are possible through local control and APP with Bluetooth.



(iOS / Android)

- Available communication solutions: Modbus RTU RS485, Profibus DP V0.
- Temperature of motor and electronic components is monitored.
- Non-intrusive design allows setting and adjusting without cover removal.
- Multi-language LCD display incorporated with reed switches makes operating, setting, adjusting easy and simple.
- Automatic phase correction and phase loss protection.
- Instantaneous reversal protection.
- Four levels of assigned password protection hierarchical prevent unauthorized changes.

[M Series] Multi-turn Electric Valve Actuator

3 Product Mechanical Data

3.1 Parts Identification



Figure 1 Actuator



Figure 2 Gear Box

SUN YEH ELECTRICAL IND. CO., LTD.

3.2 Nameplate Instruction

Service Unique N	ice Youthful Energy Honesty	
SUN YEH ELECTRICA No. 68, Ln. 854, Sec. Dadu Dist., Taichung City	L IND. CO., LTD. 1, Shatian Rd., 7 432403, Taiwan	
Multi-turn Electric	Valve Actuator	
Model No.: Max. Torque / Thrust:		
Motor Power:	Lubricant:	
Output Speed:	Enclosure:	
Voltage: Cui	rent (60/50HZ):	
Serial No.:	Weight:	
W/D Code:		
-Please read operation manu	al and wiring diagram	
-Verify that supply voltage is	in accordance with	
the data on nameplate to pre	event short circuit or	
electrical / electronic parts da	amage. o or maintenance	
-Actuator should be installed	in an upright or	
horizontal position. Do not m	nount upside down or	Cau
below a horizontal position.	le the actuator or	
valve.		
-Return the manual wrench t	o the original position	
-Use supply wires suitable fo	r at least 75°C.	
www.sunye	h.com	
4		
		/

tion

3.3 Technical Data

	Non-rising stem				m Rising stem										
	Output	Factory		ar	Max Stem	Max Stem			May	Max Stem			Mounting		
Model	Speed	Setting	Max		Acceptance	Weight		Thrust			Acceptance	W	eight	Flange	
			101	que	Diameter		Diameter								
	rpm	rpm	Nm	in·lb	mm	kg	lb	kgf	lbf	kN	mm	kg	lb	ISO 5210	
M-41	40 - 120	40	41	363											
M-55	30 - 90	30	55	487				4000	0004	10	20		101.5	F10	
M-80	20 - 60	30	80	708	35	52	52 115	2 115	4080	8996	40	28	55	121.5	F10
M-100	15 - 45	30	100	00 885											

* There are five speeds can be chosen, refer to 8.7.4 (P.48) for setting.

3.4 External Gear Box

• G201 Multi-turn Gearbox

			Non-rising stem					Rising stem						
Model	Output Speed	Factory Setting	M To:	lax rque	Max Stem Acceptance Diameter	We	eight		Max Thrust		Max Stem Acceptance Diameter	We	eight	Mounting Flange
	rpm	rpm	Nm	in·lb	mm	kg	lb	kgf	lbf	kN	mm	kg	lb	ISO 5210
M-41	13 - 40	13	123	1090										
M-55	10 - 30	10	165	1460	40	22	48.5	7140	15744	70	32	25	55.1	F12
M-80	7 - 20	10	240	2125										

• G202 Multi-turn Gearbox

			Non-rising stem					Rising stem						
Model	Output Speed	Factory Setting	M To:	Iax rque	Max Stem Acceptance Diameter	We	Weight		Max Thrust	Max Stem Acceptance Diameter	We	ight	Mounting Flange	
	rpm	rpm	Nm	in·lb	mm	kg	lb	kgf	lbf	kN	mm	kg	lb	ISO 5210
M-41	8 - 24	8	205	1815										
M-55	6 - 18	6	275	2435	45	25	55.1	10200	22491	100	36	27.5	60.6	F14
M-80	4 - 12	6	400	3540										

• G203 Multi-turn Gearbox

			Non-rising stem					Rising stem						
Model	Output Speed	Factory Setting	N To	lax rque	Max Stem Acceptance Diameter	Weight		Max Thrust			Max Stem Acceptance Weight Diameter		Mounting Flange	
	rpm	rpm	Nm	in·lb	mm	kg	lb	kgf	lbf	kN	mm	kg	lb	ISO 5210
M-41	5.7 - 17.1	5.7	285	2520										
M-55	4.3 - 13	4.3	385	3410	(0)	22.5	71.6	15200	22727	150	4.4	26	70.4	F1
M-80	2.8 - 8.6	4	560	4960	60	60 32.5	/1.6	15300	33/3/	150	44	36	/9.4	F16
M-100	2.1 - 6.4	4	700	6200										

4 Storage, Transport and Packaging

4.1 Receiving / Inspection

- Carefully inspect the package for any damages resulting from shipping and report all damages to the freight carrier and seller.
- After unpacking the product and information packet, please keep the cartons and any packing materials in case of product return or replacement. Verify that the items on the packing slip or on the bill of lading are the same as what were ordered. If there is any discrepancy, please contact the seller.
- Verify if the technical data on nameplate is in accordance with what was ordered.

4.2 Storage

- The actuator should be stored in a dry area with relative humidity of less than 90 % and at temperatures between -20 °C to +40 °C (-4 °F to +104 °F).
- The product shall be stored with suitable protection from corrosive substance that can damage the metal and insulating parts.
- The water-proof plug should not be removed until the actuator is ready to be cabled. Use suitable cable glands with IP68 rating (8 m, 120 hrs). Ensure that the water-proof plug is securely tightened for any unused conduit entries.

4.3 Transport

- Please refer to **3.3 Technical Data** and **3.4 External Gear Box** for the weight of the actuator and external gearbox and confirm the lifting tools can bear the total weight of the device, including actuator, gearbox and valve before lifting.
- Make sure the conduit entries are not upside down when lifting the actuator (Picture below).





Correct: The conduit entries are facing down.

Error: The conduit entries are facing up.

- The gear train has been sufficiently lubricated at the factory. Do NOT lift upside down to avoid the mechanism failure in case the gears could not soak in the lubricating oil completely.
- When lifting the actuator, the rope or hook shall be fixed on the shell, not on the hand wheel, and the actuator shall be kept in a balanced state to prevent tilting and sliding. For the hanging method, please refer to 4.3.1 lifting schematic diagram.
- Perform the lifting trials at a lower height to eliminate any potential danger before lifting at a higher height.
- Actuators packaged in cartons can stand up to land, sea, or air transportation.
- Packaged actuators shall avoid of violent impact and strong vibrations and be protected from rain or snow.

SUN YEH ELECTRICAL IND. CO., LTD.

4.3.1 Lifting Schematic Diagram

A Please confirm the lifting tools can bear the total weight of the device, including actuator, gearbox and valve before lifting.







[Actuator]

[Gear Box]

[Actuator and Gear Box **]**

5 Mounting

5.1 Preparing Actuator Drive Bush



Figure 1 Non-thrust Base Assembly (Non-Rising Stem)

Figure 2 Thrust Base Assembly (Rising Stem)

- a. Loosen M5 screws from the base assembly of the actuator or gearbox and dismantle the components. Remove the drive bush from base assembly.
- b. Machine the drive bush to suit the valve stem.
- c. Reassemble the base assembly and fasten M5 screws.

Make sure if the screw hole is in the right position.



Screw Size	Torque (Nm)
M5	4.2

5.2 Mounting Actuator with Valve

• Rising Stem



- a. Apply a small quantity of grease to the valve stem [5].
- b. Screw the thrust base assembly [3] into the valve stem [5] until it is flush with the valve flange. Then keep rotating the thrust base assembly [3] until alignment of the fixing holes.
- c. Fasten M10 screws [6], but do not tighten completely.
- d. Mount the actuator [1] with the thrust base assembly [3], to ensure the stem nut is engaged with the output drive sleeve [2] (see photo on the right).

▲ If the flanges are flush with each other, the actuator [1] will be engaged with thrust base assembly [3] properly.

- Adjust the actuator [1] until alignment of mounting holes on the thrust base assembly [3].
- f. Use M10 screws 【4】 to fasten the actuator 【1】 with the thrust base assembly 【3】 and fasten actuator screws (M10).

Screw Size	Torque (Nm)
M10	35

g. Tighten M10 screws [6].

Screw Size	Torque (Nm)
M10	35



SUN YEH ELECTRICAL IND. CO., LTD.

• Non-rising Stem



- a. Use M10 screws [4] to fasten the non-thrust base assembly [3] with the actuator [1]. Screw Size Torque (Nm) M10 35
- b. Mount the actuator [1] with the valve stem [5] until it is flush with the valve flange.
- c. Adjust the actuator [1] until alignment of the fixing holes and ensure the stem nut of non-thrust base assembly [3] is engaged with the output drive sleeve

(2) (see photo on the right).

- If the flanges are flush with each other, the actuator
 [1] will be engaged with the non-thrust base assembly [3] properly.
- d. Tighten M10 screws [6].

Screw Size	Torque (Nm)
M10	35

Â

- Use suitable screws and couplings to direct mount with the valve.
- DO NOT lift the actuator through the handwheel while moving to avoid actuator damage.
- The basic setting is finished if the actuator is mounted with the valve when ex-factory.



5.3 Mount Gear Box with Valve

• Rising Stem



- a. Apply a small quantity of grease to the valve stem [5].
- b. Screw the thrust base assembly [3] into the valve stem [5] until it is flush with the valve flange. Then keep rotating the thrust base assembly [3] until alignment of the fixing holes.
- c. Fasten the screws [6], but do not tighten completely.
- d. Mount the gear box [1] with the thrust base assembly [3] to ensure the stem nut is engaged with the output drive sleeve [2] (see photo on the right).

▲ If the flanges are flush with each other, the gear box [1] will be engaged with the thrust base assembly [3] properly.

- Adjust the gear box [1] until alignment of mounting holes on the thrust base assembly [3].
- f. Use the screws [4] to fasten the gear box [1] with the thrust base assembly [3].

Gear Box	Screw Size	Torque (Nm)
G201	M12	61
G202	M16	151
G203	M20	208

g. Tighten the screws [6].

-						
Gear Box	Screw Size	Torque (Nm)				
G201	M12	61				
G202	M16	151				
G203	M20	208				



SUN YEH ELECTRICAL IND. CO., LTD.

• Non-rising Stem



a. Use the screws [4] to fasten the non-thrust base assembly [3] with the gear box [1].

Gear Box	Screw Size	Torque (Nm)
G201	M12	61
G202	M16	151
G203	M20	208

b. Mount the gear box [1] with the valve stem [5] until it is flush with the valve flange.

c. Adjust the gear box [1] until alignment of the fixing holes and ensure the stem nut of non-thrust base assembly [3] is engaged with the output drive sleeve [2] (see photo on the right).

If the flanges are flush with each other, the gear box [1] will be engaged with non-thrust base assembly [3] properly.



d. Tighten the screws [6].

Gear Box	Screw Size	Torque (Nm)
G201	M12	61
G202	M16	151
G203	M20	208



5.4 Mounting Actuator with Gear box



- a. Ensure that the O-ring [2] fits uniformly in the recess of the gear box.
- b. Mount the actuator [1] with gear box [3] and align the input shaft of the gear box [3].
- c. Rotate the actuator [1] to let the flange hole of the gear box align with the flange hole of the gear box [5].
- d. Tighten M10 screws [4] per the table below.

Screw Size	Torque (Nm)
M10	35

[1] Dust-proof Cover [2] Dust-proof Stem Protection Sleeve

5.5 Mounting Dust-proof Stem Protection Sleeve

- a. Remove the dust-proof cover [1] from gear box [3].
- b. Place the dust- proof stem protection sleeve [2] on the gear box [3] and tighten with the gear box [3].

[3] Gear box

c. Tighten the dust-proof cover [1] with the dust-proof stem protection sleeve [2].

6 Electrical Connection

6.1 Terminal Block Layout

 \wedge

- Verify supply voltage is in accordance with the data on nameplate.
- The handling shall follow the safety and warning instruction. The user should read and follow instructions contained in this operation manual.
- Installation, maintenance and repair works must be performed by trained personnel.
- Wiring according to the order-related wiring diagram and keep it after wiring. Please contact your sales representatives in case of loss.
- For short-circuit protection, a switch or circuit breaker must be included in the wiring installation.



6.2 Removing Terminal Cover



▲ Ensure all power supplies are isolated before removing the cover.

- a. Loosen the cover screws [3] and remove the terminal cover [4]
 A Please do not lose the O-ring [2].
- b. Tighten the conduit entries with suitable cable glands with IP68 (8 m, 120 hrs) rating.
- c. Unused conduit entries [6] have to be sealed with plugs to reach IP68 (8 m, 120 hrs) rating.

6.3 Electrical Connection - Cable Connection

• Terminal cross section and tightening torques

Туре	Cross Section (mm ²)	Torque (Nm)
Power terminals (L1, L2, L3) & PE connection	5	2
Control contacts (1-52)	4	1

- a. Connect cables according to the order-related wiring diagram.
 - **A** Risk of electric shock in case a protective earth conductor is NOT connected!
 - ▲ Start running the device only after having connected the protective earth conductor inside actuator.
- b. Tighten PE conductor firmly to PE \bigoplus connection.



7 Manual Operation

- Incorrect settings may lead to valve damage.
- Perform all basic settings including stroke limitation for open and close direction prior to operation.
- For purposes of setting and verifying, the actuator can be operated manually in case of motor failure or power outage. Manual operation is engaged by an internal changeover mechanism. Remove the lock for manual operation in any time and relock after using manual operation. Even if supply power to actuator during manual operation, it will not switch from manual to electric operation and cause personal injury.

7.1 Manual Operation Steps

- a. Disengage motor operation before manual operation
- b. Remove the lock from handwheel lever.



c. Reverse the lever to engage handwheel for manual operation. Meanwhile, the LCM screen displays "Manual OP Action" and local operation or setting by push button will not be possible.



d. Turn the handwheel in desired direction.

▲ Clockwise turning of handwheel leads to close the valve.



- e. Disengage manual operation
 - Turn the handwheel lever back to initial position. Rotate the handwheel back and forth until a click is heard. Meanwhile, the LCM screen **NOT** displays "D" and "Manual OP Action". Put the lock back after disengaging the manual override.
 - No matter the actuator is powered or not, manual operation is always possible. To prevent misuse after using the manual operation, it is needed to turn the handwheel lever back and lock up.
 - ▲ It is needed to reset the limit position if manual operation without main power supply or battery dead. Refer section 8.7.4 to reset the limit positon if the display shows warning messages below.





• The handwheel won't rotate while the actuator is activated by motor to prevent personal injury.



8 Electrical Operation

8.1 Introduction

8.1.1 Push Button and Display Indication



• The instruction table of the LED Indicator:

Symbol	Instruction	
С	Power.	
\land	Alarm.	
0	Opening direction or closing direction.	
Z	Operating to middle travel.	

• The setting symbol corresponds to the function in below table:

Push Button	Instruction		
€)	Back to previous level.		
•	Switch the menu item / Enter an incremental value for the parameter.		
¥	Switch the menu item / Move to next position in setting parameter.		
4	Confirm selection / Save / Go to next level.		

• The valve operation symbol corresponds to the function in below table:

Push Button	Instruction	
T	Closing direction.	
=	Opening direction.	
	Stop.	

• The shortcut key symbol corresponds to the function in below table:

Push Button	Instruction		
↓ €	Press \supset and \leftarrow at the same time to return to the standby screen.		

SUN YEH ELECTRICAL IND. CO., LTD.

[M Series] Multi-turn Electric Valve Actuator



SUN YEH ELECTRICAL IND. CO., LTD.

[M Series] Multi-turn Electric Valve Actuator



SUN YEH ELECTRICAL IND. CO., LTD.



8.1.3 Instruction for Standby Mode



- If the push buttons are not operated for more than 300 seconds, the display backlight will turn off and back to the previous level.
- The LCD will be turned off if only supply power with battery and press any push button or turn handwheel to turn on the LCD, but the backlight will not light. If the handwheel is continuously operated, the LCD will remain on. If the handwheel is not operated and the push buttons are not operated for more than 30 seconds, the LCD will turn off again for power saving.

8.1.4 Torque Curve



In standby mode, Press "⊃" button to enter the torque curve page. Press the "⊃" button again to back to standby mode.

8.1.5 Main Menu Instruction

[Main Menu]

Main Menu	
User Management	
Operation	
Status	

• The main menu includes 8 parts, of which parts 5 to 8 will be displayed only to User and above.

Itam	Function	Permission			
nem	Function	Observer	User	Dealer	
1	User Management	0	\bigcirc	0	
2	Operation	\bigcirc	\bigcirc	\bigcirc	
3	Status	\bigcirc	\bigcirc	\bigcirc	
4	Control System Settings	0	\bigcirc	0	
5	Set Maintenance Due		\bigcirc	0	
6	Parameter Setting		\bigcirc	\bigcirc	
7	System Control Setting		\bigcirc	\bigcirc	
8	Fieldbus Setting		\bigcirc	0	

8.2 User Management



• The selection parameters will be differing by different user level.

User Level	No.	Menu
Observer	1.1	Set Permission Level
	1.1	Set Permission Level
Usen / Deelen	1.2	Change Operation PW
User / Dealer	1.3	Change Password
	1.4	Recover Default PW

8.2.1 Set Permission Level



• According to the user level that you choose to enter default password as below and refer to section 8.2.2 and 8.2.3 to change the password.

User Level		Default password	Note
	User Management		If you have logged in to
Observer	Status	None	the User or above, you
	Control System Settings		do not need to enter the
	Operation	1111	password again.
User		2222	
Dealer		3333	

▲ After the user logs in, if the push button is not operated for more than 300 seconds and the LCD screen is in "Standby Mode", it will be automatically logged out.



8.2.2 Change Operation PW



• Entering the old operation password before entering the new password.

8.2.3 Change Password



- Entering the old password base on the user level before entering the new password.
- The setting symbol corresponds to the table description below :

Push Button	Function
ſ	Back to previous level to quit or enter the password.
A	Enter figures from 0 to 9.
¥	Move to different digits.
4	Save the change.

8.2.4 Recover Default PW



User Level	Recoverable Password
User	Operation password (Observer)
Dealer	Operation password (Observer), User password

• Can only recover password for permission lower than login level.

SUN YEH ELECTRICAL IND. CO., LTD. 28

8.3 Operation



A password will be required for observer level user. No need for other level users.

[Operation]

Operation	2.1
Set Local/Remote	וור
Local Operation	╸

In operation section, the operating status must be set in the "Local Control" for local operation.

Before the actuator is put into service, the following basic setting must be made.

- Power Supply Select Control System Settings \rightarrow Power Supply Select
- Battery Setting Control System Settings \rightarrow Battery Setting
- Close (Open) Limit Parameter Setting → Close/Open Setting → Close Limit Parameter Setting → Close/Open Setting → Open Limit

8.3.1 Set Local / Remote



Select Local Control or Remote Control mode then press \[---] button and the display shows "Save". The setting is completed when the "Save" message is disappeared.

Push Button	Function
€)	Back to previous level to quit.
•	Select menu item (up).
V	Select menu item (down).
L→	Save the Change.

SUN YEH ELECTRICAL IND. CO., LTD.

[M Series] Multi-turn Electric Valve Actuator





Local Operation" will be available only when the operating status is set in "Local Control" mode.

Push Button	Symbol	Function	
¢		 Back to previous level and stop operating. In operating condition, push the button to stop operating and push again, it will be back to previous level. 	
•	 	 Operating in OPEN direction. Push the button to operate in OPEN direction and release the button to stop operating. Push and hold the button for more than 5 secs and "Latching" is shown, which means the actuator is in automatic running state. Push the button again to stop operating. 	
¥	T	 Operating in CLOSE direction. Push the button to operate in CLOSE direction and release the button to stop operating. Push and hold the button for more than 5 secs and "Latching" is shown, which means the actuator is in automatic running state. Push the button again to stop operating. 	
L→		Not applicable.	

SUN YEH ELECTRICAL IND. CO., LTD.





• The actuator is not operated in the following condition and warning message will be shown on the display.

	Warning Message	Description
а	Power Supply Fault	Main power failure (AC power failure).
b	Set Travel Limit	Abnormal Open / Close Limit setting or Open / Close limits are not set.
с	Manual OP Fault	Handwheel sensor signal failure.
d	d Marguel OD Asting	Handwheel lever open.
u	Manual OF Active	(At Manal Operation status)
e	Encoder Fault	Encoder sensor signal failure.
f	Driver Comm. Error	Abnormal motor driver module.
g	Motor Drive Fault	Abnormal motor running.
h	Motor Temp. Fault	Motor temperature sensing signal failure.
i	Motor OH-Stop	Motor temperature higher than 135° C (275°F).
j	Driver Overheat	Motor power module (IGBT) temperature higher
	Driver Overheat	than 125°C (257 °F).
k	EEPROM Fault	The PCBA module failure to save the data.

• The following warning messages will be shown on the display but the motor still can be operated.

	Warning Message	Operating Condition
a	Over Limit Range	When actuator exceeds the limit value set in the running direction, it needs to be operated in the opposite direction.
b	Motor OH - RPM Limit	Motor temperature is higher than the setting value thus the actuator is running at the lowest speed.
с	Close Overload Open Overload	When the torque switch is activated, the motor will be stopped. The actuator could be operated "Only" in the opposite direction.

• When Encoder failure, the backup Encoder will start running to keep saving the travel position during manual operation.

SUN YEH ELECTRICAL IND. CO., LTD.

8.4 Status



No.	Menu
3.1	Motor Status
3.2	Operating Status
3.3	Alarm Log
3.4	Product Info

8.4.1 Motor Status

Motor Status	3.1.1
Current) •
Temp.	
Driver Temp.	

No.	Menu
3.1.1	Current
3.1.2	Temp.
3.1.3	Driver Temp.

[Current]



This value will only be displayed when the motor is running.

[Temp.]



8.4.2 Operating Status

Operating Status	3.2.2
Maintenance: Undue	•
Cum. Runtime	
Cumulative Starts	

No.	Menu	
3.2.1	Maintenance : Undue / Due	
3.2.2	Cum. Runtime	
3.2.3	Cumulative Starts	
3.2.4	Cum. Torq Ovld Nos.	
3.2.5	Starts till Due	
3.2.6	Overtorques till Due	
3.2.7	Motor RT till Due	

[Maintenance]

• Display shows whether the actuator need to do maintenance or not.

[Cum. Runtime]

Cum. Runtime
Cum. Boot Time
22:03:45
Motor Cum. Runtime
12:01:22

- Cum. Boot time : total Actuator operating time
- Motor Cum. Runtime: total Motor operating time.

[Cumulative Starts]



- The starting times for OPEN and CLOSE direction.
- The total times for operating to fully- open or fullyclosed position. Only calculate the times when the actuator operating to 0% or 100% position.

Push Button	Function
€)	Back to previous level to quit.
•	Switch menu item (up).
*	Switch menu item (down).
Ļ	Not applicable.

[Cum. Torq Ovld Nos.]



The value shows the times of actuator overload and stop running.

[Starts till Due]



The value shows the remaining cycle times before maintenance.

[Overtorques till Due]

Overtorques till Due 300000 times

• The value shows the remaining overload times before maintenance.

[Motor RT till Due]



The value shows the remaining operating hours before next maintenance.

[M Series] Multi-turn Electric Valve Actuator

8.4.3 Alarm Log



Fault code for the fault event. Refer to troubleshooting for more information and soloutions.

Alarm No. for the number of alarm event. The max. number of events is 99. The oldest data will be coveredd if it is more than 99. The smallest figure means the latest message.

Short description of the Fault code.

Time for fault occurred. The time is based on th actuator boot time. (hour : minute : second)

Push Button	Function
Ð	Back to previous level to quit.
•	Switch to previous fault message.
¥	Switch to next fault message.
4	Not applicable.
8.4.4 Product Info

[Product Info]

Product Info	3.4.1
Company: SunYeh	
Model No: M-100 + G201	
S/N: SA209901001	
Firmware: Ver 0062	

[Product Info]

Produ	ict Inf	0		3.4.3
AI:⊠		AO: 🗹	Ø	
DI:⊠		DO: 🗹		
☑ Modbus				
✓ Profibus				

- Except-Firmware, the other information can be modified by Modbus, Profibus and Bluetooth protocol. G201 stands for the gearbox. It will not be shown if external gearbox is not assembled in manufactory.
- \square The module is installed.
- \Box The module is not installed.
- A/I, A/O, D/I and D/O can be installed in channel 1 (left column) or 2 (right column).

Push Button	Function
€)	Back to previous level to quit.
A	Switch to Product Info (up).
¥	Switch to Product Info (down).
Ļ	Not applicable.

8.5 Control System Settings

Control System Settings	4.1
Language	
LCD Contrast	
Lamp Color	

No.	Menu	Lowest User Level
4.1	Language	User
4.2	LCD Contrast	User
4.3	Lamp Color	User
4.4	Battery Setting	User
4.5	Power Supply Select	Dealer

8.5.1 Language



• Set the language displayed on the LCD interface.

Push Button	Function
IJ	Back to previous level to quit.
*	Switch menu item (up).
*	Switch menu item (down).
4	Save the change.

8.5.2 LCD Contrast



Push Button	Function
€)	Back to previous level to quit.
A	Contrast increase.
\checkmark	Contrast reduction.
┛	Save the change.

8.5.3 Lamp Color

Lamp Color	4.3.1 Set by the user.
✓ Red => Close	In the middle travel
Green => Close	Opening and closing indication.
	Fault indication (LED is flashing).
	• LE Power indication.
LED	Description
Power	The LED indication will stay ON after power is supplied.
Fault	The LED indication will keep blinking when the fault is

Foult	1 0
Taun	detected.
Opening and Closing Direction	The lamp colors can be set by the user. The LED indication
	will keep blinking when the actuator runs to opening or
	closing direction.
	The LED indication will stay ON when the actuator runs to
	fully-open or fully-close direction.
Middle Travel	The LED indication will stay ON when the actuator runs to
	middle travel no matter it is running or stops.

Push Button	Function
Ų	Back to previous level to quit.
•	Switch menu item (up).
\checkmark	Switch menu item (down).
Ļ	Save the change.

8.5.4 Battery Setting

Battery Setting 4.4.1	
✓ No Battery	•
Alkaline	
Lithium	

- ▲ If the actual battery specification is different from the "Battery Setting", it will cause the wrong battery warning message.
- Two types of batteries, "alkaline battery" or "lithium battery", could be installed in the actuator, and setting the correct type depending on the installation.

Push Button	Function
Ð	Back to previous level to quit.
•	Switch menu item (up).
V	Switch menu item (down).
Ļ	Save the change.

8.5.5 Power Supply Select



▲ If the actual supply voltage is different from the setting on "Power Supply Select", it will cause the wrong warning message.

• Set the power supply based on the power supply and press $\lceil \checkmark \rfloor$ to save the selection.

Push Button	Function		
€)	Back to previous level to quit.		
•	Switch menu item (up).		
\checkmark	Switch menu item (down).		
Ļ	Save the change.		

8.6 Set Maintenance Due

Set Maintenance Due	5.1	No.	Menu	Lowest User Level
Clear Maint Alarm	ווּר	5.1	Clear Maint. Alarm	User
Cheating Nee		5.2	Starting Nos.	Dealer
Starting Nos.		5.3	Torq Overload Nos.	Dealer
Torq Overload Nos.		5.4	Operating Hours	Dealer

- Set Starting Nos., Torque Overload Nos. and Operating Hours based on the user's need for maintenance.
- The Maintenance message will be displayed when one of the maintenance setting (Starting Nos., Torque Overload Nos. or Operating Hours) is reached. All Maintenance Setting will be re-accumulated after clearing alarm.

8.6.1 Clear Maint. Alarm

The display shows difference menu based on the Maintenance Signal.

[No Maintenance Signal]

Clear Maint. Alarm
No Alarm

• No Maintenance Signal and press [] to quit.

[Maintenance Signal]



• Select YES and press [] to clear all maintenance messages.

Push Button	Function		
Ð	Back to previous level to quit.		
•	Switch menu item (up).		
¥	Switch menu item (down).		
Ļ	Save the change.		

8.6.2 Starting Nos.



Push Button	Function		
Ð	Back to previous level to quit.		
*	Enter an incremental value for the parameter.		
V	Move to next digit.		
₄	Save the change.		

• Setting range is from 3 to 10,000 thousand times. For example, $30 \times 10^3 = 30,000$ times.

8.6.3 Torq Overload Nos.



Push Button	Function		
€)	Back to previous level to quit.		
•	Enter an incremental value for the parameter.		
V	Move to next digit.		
Ļ	Save the change.		

• Setting range is from 3,000 to 10,000 times.

8.6.4 Operating Hours



Push Button	Function		
€U L	Back to previous level to quit.		
•	Enter an incremental value for the parameter.		
¥	Move to next digit.		
4	Save the change.		

• Setting range is from 100 to 2,500 hours.

8.7 Parameter Setting

Parameter Setting	6.1
Motor Setting	•
Emergency Setting Torque Setting	

No.	Menu		
6.1	Motor Setting		
6.2	Emergency Setting		
6.3	Torque Setting		
6.4	Close/Open Setting		
6.5	Jam Clearance Retries		

8.7.1 Motor Setting

Motor Setting	6.1.1
	
Thermal Alarm	
Thermal Protection	

No.	Menu	Lowest User Level
6.1.1	Thermal Alarm	User
6.1.2	Thermal Protection	User

[Thermal Alarm]

Motor Setting	6.1.1	Thermal Alarm
Thermal Alarm	──╄╢∎	12 ⋒ ℃
Thermal Protection		

Push Button	Function		
ฦ	Back to previous level to quit.		
*	Switch figures from 0 to 9.		
*	Move to next digit.		
Ļ	Save the change.		

- The value could be set from 0 to 120 (Unit: $^{\circ}$ C) and default setting is 120 $^{\circ}$ C.
- When the motor temperature exceeds setting value, actuator will have warning message and an alarm log "Motor OH-RPM Limit".

[Thermal Protection]



- If the motor temperature exceeds the value set in "Thermal Alarm" and the "Thermal Protection" is set at Enable, the motor will be operated at the lowest speed. After temperature is lower than the value set in "Thermal Alarm", the actuator run at the set speed again.
- Default: Enable.

Motor High Temperature Protection

When the motor temperature is higher than 135°C (275°F), the protection function will be activated automatically to stop the motor running.
 After the motor temperature is lower than 135°C (275°F), the protection function will be based on the setting in "Thermal Alarm " and "Thermal Protection".

8.7.2 Emergency Setting

Emergency Setting 6.2.1		
Close RPM	•	
Open RPM		
Emergency Action		

No.	Menu	Lowest User Level
6.2.1	Close RPM	User
6.2.2	Open RPM	User
6.2.3	Emergency Action	User
6.2.4	Signal Setting-NC/NO	Dealer
6.2.5	Signal Fault Action	Dealer
6.2.6	Signal Fault Position	Dealer

[Close / Open RPM]

1
л •
м м
PN

- The function is to set for Close and Open operating speed in emergency condition.
- Speed setting refers to section 8.7.4 Close / Open Settings.

Push Button	Function		
Ð	Back to previous level to quit.		
•	Switch menu item (up).		
V	Switch menu item (down).		
Ļ	Save the change.		





Push Button	Function		
€)	Back to previous level to quit.		
•	Switch menu item (up).		
V	Switch menu item (down).		
Ļ	Save the change.		

- When an ESD signal is received, the actuator will run to the desired position based on the setting of "Emergency Action". There are 4 actions can be set as following table.
- Default: Disable ESD Signal.

Menu	Description		
Run to Fully Closed	Once the ESD signal is received, the actuator will run to the		
	fully-closed position.		
Run to Fully Open	Once the ESD signal is received, the actuator will run to the		
	fully-open position.		
Stop Running	Once the ESD signal is received, the actuator will stop run-		
	ning.		
Disable ESD Signal	Once the ESD signal is received, the actuator will keep run-		
	ning normally.		

[Signal Setting -NC/NO]



- Set the wiring type of emergency signal input for Normal Close or Normal Open.
- Default: Normal Open.

Push Button	Function		
€)	Back to previous level to quit.		
•	Switch menu item (up).		
\checkmark	Switch menu item (down).		
Ļ	Save the change.		



A	Switch menu item (up).
\checkmark	Switch menu item (down).
Ļ	Save the change.

- When the emergency input signal is failed (Analog Input, Digital Input, Profibus or Modbus control modes), refer to the table below to check the corresponding action of the actuator.
- The function for Analog Input Control is only available for 4 20mA, 1 5V, 2 10V.
- Default : Stay Put

Menu	Description		
Stay Put	Once the input signal is failed, the actuator will stop running.		
Fail-safe Position	Once the input signal is failed, the actuator will operate to		
	the position set in the "Signal Fault Position".		
Preset Position	Once the input signal is failed, the actuator will keep running		
	to the position per the input signal.		
	Note: The function is only available for 4-20mA control.		



Push Button	Function		
€	Back to previous level to quit.		
•	Switch menu item (up).		
V	Switch menu item (down).		
Ļ	Save the change.		

- While the input signal is failed and the "Signal Fault Action" is set in "Fail-safe Position". The actuator will run to the position set in "Signal Fault Position".
- Setting range is from 0 to 100% and default setting is 0%.

8.7.3 Torque Setting

Torque Setting	6.3.1	No	Мени	Lowest U
Tora Limit-Close		110.	Wienu	Level
Torg Limit-Open	[]	6.3.1	Torq Limit-Close	User
Torq Limit-Close Mid		6.3.2	Torq Limit-Open	User
	<u> </u>	6.3.3	Torq Limit-Close Mid	User
		6.3.4	Torq Limit-Open Mid	User

[Torque Limit-Close / Open]





Push Button	Function			
€	Back to previous level to quit.			
A	Adjust tripping torque in end position.			
	One push corresponds to 10% reduction.			
`	Adjust tripping torque in end position			
	One push corresponds to 10% increase.			
Ļ	Save the change.			

- The tripping torque in end position of CLOSE / OPEN could be set from 30% to 100% and default settings are 100% for Close and 50% for Open.
- The function must be applied with "Close / Open Seating Type" and "Travel Limit-Close / Open". And, the Seating Type is set in "Torque Seating" priority.

SUN YEH ELECTRICAL IND. CO., LTD.

User

[Torq Limit-Close Mid / Open Mid]

Push Button	Function		
Ð	Back to previous level to quit.		
	Adjust tripping torque in mid-travel.		
	One push corresponds to 10% reduction.		
~	Adjust tripping torque in mid-travel.		
•	One push corresponds to 10% increase.		
4	Save the change.		

- The tripping torque in CLOSE and OPEN mid-travel. If the actuator is stuck in the mid-travel (per tripping torque setting), the actuator will perform the Retry function until programmed number of tries set in "Jam Clearance Retries" is reached.
- The function must be used with "Jam Clearance Retries".
- Default: 50%.

8.7.4 Close/Open Setting

Close/Open Setting	6.4
Close Tightly	
Close Direction	
Close Limit	

No	Mona	Lowest
INU.	Menu	User Level
6.4.1	Close Tightly	User
6.4.2	Close Direction	Dealer
6.4.3	Close Limit	Dealer
6.4.4	Open Limit	Dealer
6.4.5	Close RPM	User
6.4.6	Open RPM	User
6.4.7	Close Seating Type	User
6.4.8	Open Seating Type	User
6.4.9	Travel Limit-Close	User
6.4.10	Travel Limit-Open	User

[Close Tightly]



Push Button	Function		
Ð	Back to previous level to quit.		
*	Switch menu item (up).		
\checkmark	Switch menu item (down).		
Ļ	Save the change.		

- As long as the actuator runs to the desired end position, the actuator will continue to run whether the end position command is cancelled or the STOP command from remote control system is received until a torque overload occurs, 0% position has been reached or a reversal operation command is received and either OPEN or CLOSE direction can be chosen.
- Default: Disable.

[Close Direction]



Push Button	Function		
Ð	Back to previous level to quit.		
•	Switch menu item (up).		
\checkmark	Switch menu item (down).		
Ļ	Save the change.		

- Define the rotation direction of the output shaft and either "CW to Close" or "CCW to Close" can be chosen.
- Default : CW to Close



Push Button	Function			
Ð	Back to previous level to quit.			
*	Push the button to operate in direction CCW and release the button to stop running.			
*	Push the button to operate in direction CW and release the button to stop running.			
Ļ	Save the change.			

- The "Close/Open limit" can be set only when the operating status is set in "Local Control" mode.
- Output shaft turns and related info will be displayed as shown below under "Close Limit" and "Open Limit".



Real-time percentage of torque when the actuator is running.

Press and hold the button for more than 5 secs and "L" is displayed which means the actuator is in automatic running state. Press the button once to stop running.

The operation direction is displayed as below conditions:

- CW means the output shaft turns in clockwise direction and CCW means in counter-clockwise direction.
- Operating direction icon in CW or CCW.
- Arrow icon in right or left direction.



Push Button	Function		
Ð	Back to previous level to quit		
•	Switch menu item (up)		
\checkmark	Switch menu item (down).		
Ļ	Save the change.		

• The setting of Close/Open RPM as shown below:

Actuator

Model	Running Speed (RPM)	Default (RPM)
M - 41	120, 100, 80, 60, 40	40
M - 55	90, 75, 60, 45, 30	30
M - 80	60, 50, 40, 30, 20	30
M - 100	45, 37, 30, 22, 15	30

Actuator with external gearbox

▲ The RPM value for actuator with external gearbox must be preset be fore shipping or be modified via Modbus, Profibus or Bluetooth.

Otherwise, the RPM value will be based on below default value.

Actuator	Gearbox	Running Speed (RPM)	Default (RPM)
M-41	G201	40, 33, 27, 20, 13	13
M-55	G201	30, 25, 20, 15, 10	10
M-80	G201	20, 17, 13, 10, 7	10

Actuator	Gearbox	Running Speed (RPM)	Default (RPM)
M-41	G202	24, 20, 16, 12, 8	8
M-55	G202	18, 15, 12, 9, 6	6
M-80	G202	12, 10, 8, 6, 4	6

Actuator	Gearbox	Running Speed (RPM)	Default (RPM)
M-41	G203	17.1, 14.3, 11.4, 8.6, 5.7	5.7
M-55	G203	13, 11, 9, 6, 4.3	4.3
M-80	G203	8.6, 7, 6, 4, 2.8	4
M-100	G203	6.4, 5, 4, 3, 2.1	4

Close Seating Type 6.4.7 Close RPM Close RPM Open RPM Travel Seating Close Seating Type Torque Seating

Push Button	Function
U	Back to previous level to quit.
•	Switch menu item (up).
\checkmark	Switch menu item (down).
4	Save the change.

- The actuator in CLOSE end position can be set to trip by Position or Torque.
- Position: After entering the travel limit, the tripping torque will be set automatically at 100% and the actuator will run to fully-closed position (0%) when the torque is lower than 100%.
- Torque: After entering the travel limit, the tripping torque will be set per the setting value at "Torque Limit-Close" and the actuator will stop running immediately when the torque is higher than the setting value. Besides, the actuator will run to fully-closed position (0%) when the torque is lower than setting value.
- Default: Position.

[Open Seating Type]

Close/Open Setting	6.4.8	<u>,</u>	Open Seating Type
Open RPM Close Seating Type			✓ Travel Seating
Open Seating Type]		

Push Button	Function
€)	Back to previous level to quit.
A	Switch menu item (up).
¥	Switch menu item (down).
	Save the change.

- The actuator in OPEN end positions can be set to trip by Position or Torque.
- Position: After entering the travel limit, the tripping torque will be set automatically at 100% and the actuator will run to fully-open position (100%) when the torque is lower than 100%.
- Torque: After entering the travel limit, the tripping torque will be set per the setting value at "Torque Limit-Open" and the actuator will stop running immediately when the torque is higher than the setting value. Besides, the actuator will run to fully-open position (100%) when the torque is lower than setting value.
- Default: Positon

[Travel Limit-Close]



Push Button	Function
Ð	Back to previous level to quit.
•	Switch menu item (up).
\checkmark	Switch menu item (down).
Ļ	Save the change.

- Set the Travel Limit-Close and the setting range is from 2% to 20%.
- After entering the travel limit, the functions of the "Close Seating Type" and "Torque Limit-Close" will be activated.
- Default : 10%.



Push Button	Function
ฦ	Back to previous level to quit.
•	Switch menu item (up).
\checkmark	Switch menu item (down).
Ļ	Save the change.

- Set the Travel Limit-Open and the setting range is from 80% to 98%.
- After entering the travel limit, the functions of the "Open Seating Type" and "Torque Limit-Open" will be activated.
- Default: 90%.

8.7.5 Jam Clearance Retries



No.	Menu	Lowest User Level
6.5.1	Close Middle Travel	User
6.5.2	Open Middle Travel	User

[Close Middle Travel]



Push Button	Function
U	Back to previous level to quit.
*	Enter an incremental value for the parameter.
\checkmark	Not applicable.
Ļ	Save the change.

• The actuators provide jammed valve protection by torque sensing. If the actuator stops because of overload during intermediate travel in closing the valve. A retry sequence can be initiated by setting the parameter from 0 to 5 to achieve the number of retries as per application requirements. Zero stands the retry is not implemented.

- When a torque overload occurs, a retry sequence will be initiated by setting the parameters as following:
 - Set to 0: The actuator will stay put and send a warning message when a torque overload occurs.
 - Set to 1 2, 3, 4, or 5: The actuator will move back for 3% of the entire travel and then move forth to attempt to fix the jammed valve repeatedly by 1, 2, 3, 4, or 5 tries. In case of failure to pass the block, the actuator will run to opposite direction about 3% of stroke and stop running to send a warning message.
- Default: 0.
 - **Note:** If the operating time of moving back for 3% of the entire travel is less than 3 seconds, the actuator will increase it to more than 3 seconds to ensure effectiveness of the jammed valve protection.

[Open Middle Travel]



Push Button	Function
ฦ	Back to previous level to quit.
•	Enter an incremental value for the parameter.
V	Not applicable.
Ļ	Save the change.

- The actuators provide jammed valve protection by torque sensing. If the actuator stops because of overload during intermediate travel in opening the valve. A retry sequence can be initiated by setting the parameter from 0 to 5 to achieve the number of retries as per application requirements. Zero stands the retry is not implemented.
- When torque overload, a retry sequence will be initiated by setting the parameters as the following:
 - Set to 0: The actuator will stay put and send a warning message when a torque overload occurs.
 - Set to 1, 2, 3, 4, or 5: The actuator will move back for 3% of the entire travel and then move forth to attempt to fix the jammed valve repeatedly by 1, 2, 3, 4, or 5 tries. In case of failure to pass the block, the actuator will run to opposite direction about 3% of stroke and stop running to send a warning message.

• Default: 0.

Note: If the operating time of moving back for 3% of the entire travel is less than 3 seconds, the actuator will increase it to more than 3 seconds to ensure effectiveness of the jammed valve protection.

8.8 System Control Setting

System Control Setting	
Input Source	
Analog Channel	
Digital Channel	

No.	Menu	
7.1	Input Source	
7.2	Analog Channel	
7.3	Digital Channel	

8.8.1 Input Source



No	Мори	Lowest User
140.	Ivičnu	Level
7.1.1	Digital Permanent	Dealer
7.1.2	Digital Pulse Input	Dealer
7.1.3	Analog Input	Dealer
7.1.4	Modbus	Dealer
7.1.5	Profibus	Dealer

[Digital Permanent]



[Digital Pulse Input]

Input Source	7.1.2	
Digital Permanent		
✓ Digital Pulse Input		
Analog Input		



[Analog Input]



SUN YEH ELECTRICAL IND. CO., LTD.

Push Button	Function			
U	Back to previous level to quit.			
*	Switch menu item (up).			
\checkmark	Switch menu item (down).			
Ļ	Save the change.			

- Symbol " \checkmark " in front of the item represents current setting.
- Only "Digital Permanent", "Digital Pulse Input" and "Analog Input" Channels need to set channel 1 or 2. Modbus and Profibus do not need to set.
- After setting the channel of "Analog Input", "Analog Channel" (refer to section 8.8.2) need to be set as well.
- Two signal types for Digital Control: "Digital Permanent" and "Digital Pulse Input".

Eurotion	Digital Control			
Function	Digital Permanent	Digital Pulse Input		
Run Close	V	V		
Stop	V	V		
Run Open	V	V		
ESD	V	Δ		
Disable Close	V	Δ		
Disable Open	V	Δ		

 $[\]Delta$: It is needed to have a continuous signal to activate. When "Digital Pulse Input" is selected, it only works in the pulse rise time.

"Digital Permanent" is a continuous signal type, which means that actuator will operate when a continuous signal is present.

It is needed to set "NO" (Normal Open) or "NC"(Normal Close) (refer to section 8.8.3) as well.

"Digital Pulse Input" is a trigger mode, which means that actuator will operate when a pulse signal is present.

- > A signal will be trigged when the pulse rise edge is received.
- Once any stop signals are received such as manual override enable, torque overload and so on, a pulse signal needs to be present again to continue the operation.
- While the "ESD", "Disable Close" or "Disable Open" is active, the "Run Close", "Stop" and "Run Open" functions will be invalid.

8.8.2 Analog Channel

Analog Channel	7.2.1	No.	Menu	Lowest User Level
Set A/I Sensitivity		7.2.1	Set A/I Sensitivity	Dealer
A/I Signal Type		7.2.2	A/I Signal Type	Dealer
A/O Signal Type	I	7.2.3	A/O Signal Type	Dealer
		7.2.4	Analog Output Channel	Dealer

[Set A/I Sensitivity]

Analog Channel	7.2.1	Set A/I Sensitivity
Set A/I Sensitivity		
A/I Signal Type		U.5 %
A/O Signal Type		0.0 5.0

Push Button	Function				
Ð	Back to previous level to quit.				
A	Enter figures from 0 to 9.				
¥	Move to next digit.				
4	Save the change.				

- When the sensitivity setting is higher, the resolution of the input signal will be higher, and the dead band will be smaller.
- The sensitivity setting range is 0.0~5.0%. When 0.0% is set, the allowable tolerance is 0%, which is the most sensitive state. When 5.0% is set, the allowable tolerance is ±5%, which is the most insensitive state.
- Default: 0.5 %.

[A/I Signal Type]

Analo	og Channel	7.2.2		A/l Signal Type	1
Set /	A/I Sensitivity Signal Type	∳║ ■		0-20 mA ✓ 4-20 mA	•
A/0	Signal Type			0-5 V	
	Push Button		Funct	ion	
	U	Back to pre	vious level to	o quit.	
	*	Switch mer	nu item (up).		
	*	Switch mer	nu item (down	ı).	
	Ļ	Save the ch	ange.		

[A/O Signal Type]

Analog Channel	7.2.3	A/O Signal Type	1
Set A/l Sensitivity A/l Signal Type		0-20 mA ✓ 4-20 mA	
A/O Signal Type		0-5 V	

Push Button	Function		
f)	Back to previous level to quit.		
•	Switch menu item (up).		
*	Switch menu item (down).		
↓	Save the change.		

[Analog Output Channel]

Analog Channel	7.2.4	Analog Output Channel
A/I Signal Type A/O Signal Type Analog Output Channel		✓ Channel 1 Channel 2

Push Button	Function			
IJ	Back to previous level to quit.			
*	Switch menu item (up).			
*	Switch menu item (down).			
Ļ	Save the change.			

• There are six signal types for A/I Signal Type and A/O Signal Type as shown below and different signals can be set for A/I and A/O.

Signal Type		
0 - 20 mA		
4 - 20 mA		
0 - 5 V		
1 - 5 V		
0 - 10 V		
2 - 10 V		

8.8.3 Digital Channel

Digital Channel 7.3.1		
Digital Input-NC/NO	•	
Digital Output -CH1		
Digital Output -CH2		

No.	Menu	Lowest User Level
7.3.1	Digital Input-NC/NO	Dealer
7.3.2	Digital Output-CH1	User
7.3.3	Digital Output-CH2	User

[Digital Input-NC/NO]



• Set "Normal Close" or "Normal Open" for the wiring of digital input.

Push Button	Function
Ð	Back to previous level to quit.
A	Switch menu item (up).
¥	Switch menu item (down).
4	Save the change.

[Digital Output-CH1 / CH2]

Digital Channel	7.3.2		Digital Output -C	H1
Digital Input-NC/NC			RY 1 Output Fun	oction
Digital Output -CH1			RY 2 Output Fun	iction
Digital Output -CH2			RY 3 Output Fun	oction
Push Button	Fu	nction		
€	Back to previous leve	l to quit.		
A	Switch menu item (up)).		
×	Switch menu item (do	own).		
4	Save the change.			

• Channel 1 and channel 2 for Digital output: There are 4 output contacts for each channel.



Push Button	Function
€)	Back to previous level to quit.
A	Switch menu item (up).
\checkmark	Switch menu item (down).
4	Save the change.

• Each relay contact can be assigned to different Relay Mode, Normal Close or Normal Open. There are 17 relay output modes could be chosen and default setting is Disable. The function of each mode is as shown below table.

	Relay Output Mode		
No.	Function	Description	
1	Disable	Relay has no function.	
2	Run to Fully Closed	Fully-closed position.	
3	Run to Fully Open	Fully-open position.	
4	Torque Trip-CL Mid	Torque overload in CLOSE Direction and stops running.	
5	Torque Trip-OP Mid	Torque overload in OPEN Direction and stops running.	
6	Torquo Trip	Torque overload in either OPEN or CLOSE Direction and stops run-	
0	Torque Trip	ning.	
7	Fault	Error has occurred.	
8	Signal Flash	Relay contact is activated every second.	
0	Doody	Motor is normal, handwheel lever disables and limit position setting is	
9	Ready	completed, which means the actuator is ready for electrical operation.	
10	Remote Selected	Output signal for remote control.	
11	Motor Overheat Stop	The motor will stop running when its temperature is higher than 135° C	
11	Wotor Overneat-Stop	(275°F).	
10	Motor Overheat	If the motor temperature exceeds the setting value, the motor will run	
12	Motor Overneat	at the lowest speed until its temperature is lower than the setting value.	
13	Maintenance Due	One of maintenance settings is detected.	
14	Closing	The valve is running to close direction.	
15	Opening	The valve is running to open direction.	
16	D/I Module Fault	Input Signal Not Found.	
17	A/I Module Fault	Input Signal Not Found.	

8.9 Fieldbus Setting

Fieldbus Setting	8.1
	i
Modbus	
Profibus	

No.	Menu
8.1	Modbus
8.2	Profibus

• The Fieldbus Setting includes Modbus and Profibus.

8.9.1 Modbus

Modbus 8.1.1	1	No.	Menu	Lowest User Level
Address		8.1.1	Address	User
BaudRate		8.1.2	BaudRate	User

- Address: Set the bus address for Modbus and the setting range is from 1 to 247.
- BaudRate: Set the transmission rate for Modbus. There are 5 rates could be chosen. Refer to the following instructions.



• The LCD display shows the default value or the setting value when entering "Modbus Address" function.

Push Button	Function
ฦ	Back to previous level to quit.
*	Enter figures from 0 to 9.
\checkmark	Move to next digit.
Ļ	Save the change.

[Modbus BaudRate]	
Modbus BaudRate	5
38400	
57600	
√115200	

Push Button	Function
Ð	Back to previous level to quit.
*	Switch menu item (up).
*	Switch menu item (down).
4	Save the change.

• Symbol " \checkmark " in front of the item represents current setting.

BaudRate
9600
19200
38400
57600
115200

• Default: 115200.

8.9.2 Profibus Address

Profibus Address	No.	Menu	Lowest User Level
007	8.2.1	Address	User

• The LCD display shows the default value or the setting value when entering "Profibus Address "function and the setting range from 2 to 125.

Push Button	Function	
ฦ	Back to previous level to quit.	
*	Enter figures from 0 to 9.	
*	Move to next digit.	
Ļ	Save the change.	

9 Servicing and Maintenance

9.1 Battery Maintenance

Definition: The battery supports to record the position variation when using the manual override under power outage.

Types:

Battery Type Detail	Spec.	Quantity
Primary Alkaline battery	AA	3 PCS
Primary lithium Battery	LS 33600	1 PCS

Notices:

- Replace the battery when the main power is energized.
 - A Replacing the battery under power outage will cause the error of the data logger records.
- In normal condition, the battery needs to be replaced every 3 years. The ambient temperature and operating conditions may affect battery life.
- Remove the sealing plug with a 10 mm Alley key to ensure the O-ring exists when power is energized.
- If the actual battery specification is different from 8.5.4 Battery Setting, the "Battery Low" alarm will be displayed.

Battery Replacement:





Primary lithium Battery Type: LS 33600 Primary Alkaline battery Type: AA

- a. Remove the sealing plug with 10mm Allen key.
- b. Pull out the battery case.

Do Not pull it out too hard to cause the wires loosed.

- c. Tighten the sealing plug after replacing the battery.
- d. Set the battery type via LCD interface (Refer to section 8.5.4).

9.2 Oil Replacement

- Model: 75W80.
- Oil Capacity: 1L.
- Replacement cycle: 5 years.
 - a. Remove the top oil plug with a 8mm Allen key.



c. Tighten the oil plug back after draining the oil completely.



e. Tighten the oil plug back to the top oil hole.



b. Use a 8 mm Allen key to remove the oil plug when is located at the lower right side of the LCD panel and drain the oil completely.



d. Filled with the oil from the top oil hole. The oil capacity is 1 liter.



9.3 Maintenance

Damage might be caused by inappropriate maintenance!

- Maintenance and repair works must be performed by trained personnel.
- Turn power off before maintenance or repair.
- Carry out visual inspection every year to ensure no damage or changes.
- Ensure the wiring no damage or loose and correct wiring.
- If the paint was peeled off, the housing needs to be touched up with the paint to prevent corrosion.
- Check if the water-proof cable glands, blanking plugs and adapter are tightened and sealed.
- Check if the wiring and the terminals fade to prevent the short circuit and the failed PCBA caused by the temperature rise.
- Ensure the seals are placed correctly without hardening or damage.
- Ensure all housing screws are tightened.
- If any safety problems are detected during maintenance, the actuator must be repaired immediately without delay.
- Using the original or equivalent to replace the seals, and etc.

9.4 Operation Protection

M The following actions are required to ensure safe device operation:

- Perform the operating test every 6 months.
- Check if the cable, cable glands, blanking plugs, and etc. are tightened and sealed.
- Operate the actuator per the rated torque, or the product may be damaged under torque overload.
- If the screws which combine the actuator with the gearbox are tightened per the rec ommend torque value.
- Lubricate the valve stem and connection parts.

10 Troubleshooting

• Troubleshooting for Fault codes of the alarm log are listed as below table.

Code	Warring Message	Possible Problems	Solution
03	Motor OH- RPM Limit	 a. The temperature inside the motor is higher than the setting value and the motor will run at the re- duced speed to avoid overheating. b. The temperature setting of "Motor Tem Warn- ing" is too low. c. The duty cycle exceeded 	 a. Confirm if the torque of the valve suits for the actuator. b. Confirm if the temp. setting value not too low. c. Motor stops running
		overload.	until it cools down.
04	Motor OH-Stop	 a. The temperature inside the motor is higher than 135°C (275°F) and stops running. b. The duty cycle exceeded the rating or torque is overload. 	a. Confirm if the torque of the valve suits for the actuator.b. Motor stops running un- til it cools down.
05	Driver Overheat	The duty cycle exceeded the rating or torque is overload.	Confirm if the torque of the valve suits for the actuator.
06	Battery Low	 a. Battery capacity is low. (Lithjum battery less than 2 to 2.5V and alkaline battery less than 3 to 3.7V). b. The ambient temperature is over the rated tempera- ture of the battery. 	 a. Replace a new battery. b. Confirm the ambient temperature and change to a suitable battery.
07	Battery Missing	 a. Incorrect battery installation. b. Low battery power. (Both lithjum battery and alkaline battery less than 2V). 	a. Re-install the battery.b. Replace new battery.

Code	Warring Message	Possible Problems	Solution
08	Power Supply Fault	a. Power failure.b. PCBA failure.	 a. Check if the power supply is correct or not. b. Check if the wiring is secured. c. Replace a new power module. d. Contact the seller.
09	Phase Loss	a. Phase loss for three-phase power supply.b. Wrong actuator specifica- tion.	 a. Check if the power supply is correct. b. Reset the voltage according to actuator specification.
12	Over Limit Range	The actuator runs over the OPEN or CLOSE limited posi- tion at the range of higher than $100\% + 216^{\circ}$ or lower than 0%	Adjust to the normal range.
13	Torque Overload	a. Valve is blocked or stuck by foreign objects.b. The valve is stuck in the valve seat when the valve is inactive for a long time.	Operate the handwheel to confirm if the valve is stuck by foreign objects and re- move them.
14	Encoder Fault	a. Encoder circuit is broken.b. Poor external wiring connection.	a. Confirm if the wiring is correct or not.b. Contact the seller.
15	Motor Temp. Fault	The temperature sensor is broken.	Replace a new motor.
18	Manual OP Fault	a. Handwheel wiring is not correct.b. Poor internal wiring connection.	a. Confirm if the wiring is correct or not.b. Contact the seller.

Code	Warring Message	Possible Problems	Solution
19	Digital Input Fault	a. Poor external wiring connection.b. The PCBA is broken.	 a. Confirm if the wiring is correct or not. b. Replace a new PCBA (D/I).
20	Digital Output Fault	The PCBA is broken.	Replace a new PCBA (D/O).
21	Analog Input Fault	a. Poor external wiring connection.b. The PCBA is broken.	 a. Confirm if the wiring is correct or not. b. Replace a new PCBA (A/I).
22	Analog Output Fault	The PCBA is broken.	Replace a new PCBA (A/O).
23	EEPROM Fault	a. Data access is error.b. The memory is broken.	Replace the main board.
24	Driver Comm. Error	PCBA is broken.	Replace a new motor driver.
25	Modbus Comm. Error	 a. Poor external wiring connection. b. PCBA is broken. c. Control signal is not received for more than 2 	 a. Confirm if the wiring is correct or not. b. Replace a new Modbus module. c. Confirm if the control signal is correct or not.
26	Motor Drive Fault	a. Power supply is error.b. The motor is broken.c. The PCBA is broken.	 a. Check if the power supply is correct or not. b. Contact the seller. c. Replace a new board (Motor Driver Board).
27	Ctrl. Power Fault	a. Power supply is error.	 a. Check if the power supply is correct or not. b. Replace a new power module. c. Contact the seller.

Code	Warring Message	Possible Problems	Solution
28	Profibus Comm. Error	a. Poor external wiring connectionb. The PCBA is broken.	a. Confirm if the wiring is correct or not.b. Replace a new Profibus
		c. Control signal is not re- ceived for more than 2 secs.	module.c. Confirm if the control signal is correct or not.
29	Spare Encoder Fault	a. Encoder circuit is broken.b. Poor external wiring connection.	a. Confirm if the wiring is correct or not.b. Replace a new encoder module.
30	Position Detect Error	Operate the handwheel under power outage to cause the po- sition record error.	Reset the limit position. (re- fer to 8.7.4)

11 Warranty

Sun Yeh Ele. Co. Ltd warrants that for a period of twelve months from the date of manufacture it will either repair or replace, at its option, any of its products which prove to be defective in material or workmanship. This warranty does not cover damage resulting from causes such as abuse, misuse, modification or tampering by users. This warranty is extended only to the immediate purchaser of the Sun Yeh product and is not transferable. To obtain service under this warranty, the purchaser must first acquire a return authorization from Sun Yeh. Products must be returned to Sun Yeh under freight prepaid.

This warranty is in lieu of all other obligations, liabilities or expressed warranties. Any implied warranties, including any implied warranty of merchantability are hereby expressly excluded. In no event shall Sun Yeh be liable for special, incidental or consequential damages arising in connection with the use of its products, or for any delay in the performance of this warranty due to cause beyond its control.

12 Disposal

Please obey the local environment regulation for equipment scrapping.


SUN YEH ELECTRICAL IND. CO., LTD.

No.68, Ln. 854, Sec. 1, Shatian Rd., Dadu Dist., Taichung City 432403, Taiwan Tel: +886-4-26985666 Fax: +886-4-26983668 E-mail: service@sunyeh.com



www.sunyeh.com