

# Multi-turn Electric Valve Actuators



# OPERATION MANUAL (APP)





SUN YEH ELECTRICAL IND. CO., LTD.

SY04-I002A-EN

# Comtents

1	Installation1					
2	Bluetooth Connection					
	2.1	Conne	ection steps	2		
3 Function						
	3.1	Descr	iption	3		
		3.1.1.	Basic Information	4		
		3.1.2.	Function Options	6		
		3.1.3.	Permission Level	9		
		3.1.4.	System Settings Menu	10		
	3.2	Syster	m Settings	11		
		3.2.1.	Product Information	11		
		3.2.2.	Set Maintenance Due	11		
		3.2.3.	Control System Settings	12		
		3.2.4.	Emergency Setting	12		
		3.2.5.	Close / Open Setting	13		
		3.2.6.	System Control Setting	14		
		3.2.7.	Relay Contact	15		

## **1** Installation

▲ Language Setting: Change the preferred language on the mobile device first before opening the language setting on the SUNYEH APP.

• iOS : Search "SUNYEH" on <u>App Store</u> to download the software.





• Android : Search "SUNYEH" on <u>Google Play Store</u> to download the software.



## 2 Bluetooth Connection

#### 2.1 Connection Steps

- 1. Open the SUNYEH APP to begin the pairing process and swipe the arrow (red frame) from left to right and it will show a list of available actuators. Tap the actuator number you wish to pair with to initiate the connection.
  - ▲ The mobile device can only be paired with one actuator at a time and the user can check the serial number of currently connected actuator on the nameplate.





2. Select the permission level and enter the password.

User pe	rmission Cancel
Device Name MT_0001	
Permission Level	
User	
Password	
Password	
Cancel	login
Cancel	Confirmed
U	ser
De	aler
Admin	istrator

3. Permission Level

User Level	Default Password
User	2222
Dealer	3333

# **3** Function

### 3.1 Description



## 3.1.1 Basic Information

....



Symbol	Instruction	Symbol	Instruction
	Driver Temperature		Motor Temperature
•	Status	0 RPM	Transmission Shaft RPM
	Maintenance		Warring Message

Status : Display the current system status.

Status		Status		
Code	Message	11		Manual OP Active
1	Ready	12	2	Remote Control Active
2	Emergency Function Active	13	}	Run to Preset Position (Signal Fai
3	Fault	14	1	ESD Active
4	Limit Setting Complete			
5	Manual OP Active	15		Motor Overheat - RPM Limit
6	Remote Control Active	16	;	Motor Overheat - Stop
7	Fully-closed Position	17	'	Maintenance Required
8	Fully-open Position	18	;	Bluetooth Connecting
9	Close Overload	19	)	Retrying
10	Open Overload	20	)	Retrying Reverse OP

4



Maintenance				
Cum. Boot time: 06D/20h/41m/17s Motor Cum. Runtime: 00D/00h/05m/07s				
Overtorques till Due :	3000			
Starts till Due :	30000			
Motor Runtime till Due :	104D/04h/00m/			
Cum. Overtorque Nos. :	0 times			
Cum. Starts-Open :	5 times			
Cum. Starts-Close :	22 times			
Cum. Starts-Fully Close	: 3 times			
Cum. Starts-Fully Open	: 1 times			



Warning Message : Display the warring message to know the current fault status of the actuator.

▲ It only records the current warning message, and the warning record will be deleted after the issue is resolved.

<	Warning Message
Code	Message
1	LCD Overheat
2	MainBoard Overheat
3	Motor Overheat - RPM Limit
4	Motor Overheat - Stop
5	Driver Overheat
6	Battery Low
7	Battery Missing
8	Power Supply Fault
9	Phase Loss
10	Overvoltage
11	Ouer Limit Benne
12	Over Limit Range
13	Encoder Fault
14	Motor Temp. Fault

#### **3.1.2** Function Settings





Disconnected: Disconnect the Bluetooth .







System Settings: Parameter settings of the actuator.

System Settings	
Product Information	>
Set Maintenance Due	>
Control System Settings	>
Emergency Setting	>
Close / Open Setting	>
Systme Control Setting	>
Relay Contact Setting	>

Real Time Monitor : Monitor the current position, speed, torque, motor and driver temperature, and the monitor values can be saved as a CSV file.

- To start recording: Click the *inte* button to start recording position, speed, torque, motor temperature and driver temperature.
- During recording: The icon will turn into is to start recording and different parameters (position, speed, etc.) can be chosen. Do not quit the screen to retain recording.
- Finish recording: Once the record is finished, tap 🛗 once to export the record.



• Save files to a mobile device:

▲ Data can be saved on a mobile device with iOS system, but it can only be uploaded to iCloud Drive with Android system due to system limitation.

- Saving steps with iOS
  - After the real-time monitoring record is finished, select [Save to Files].
  - 2. Choose the location to save files on the mobile device or iCloud Drive.
  - 3. Tap save to finish the storage.



SUN YEH ELECTRICAL IND. CO., LTD.

7

- Saving steps with Android:
  - 1. After the real-time monitoring record is finished, select [Drive].
  - 2. Choose the location to save files on iCloud Drive.
  - 3. Tap save to finish the storage.

Real Time Monitor	Save to Drive
1,800	Document title
M100.csv Share via "Nearby share" Share	Account Folder
Share via realme Share     Turn on	
LINE LINE Keep Drive Gmail	Cancel Save
А	ndroid



Remote Control: The actuator can be controlled through the connection with a mobile device.



#### 3.1.3 Permission Level



• The menu will be displayed on the screen per different permissions.

User Level	Default	Instruction
	Password	
		System settings are not available. User can only read 3.1.1
User	2222	Basic Information of main screen (speed, torque, temperature,
		etc.) and perform remote control and real-time monitoring.
Deeler	2222	Besides having all the user permissions, dealer can also do
Dealer	3333	partial parameter settings.

9

#### 3.1.4 System Settings Menu



#### **3.2 System Settings**

#### **3.2.1 Product Information**



#### **3.2.2** Set Maintenance Due

- Starting Nos., Torque Overload Nos. or Operating Hours can be set per user's needs.
- The maintenance message will not be displayed until one of the maintenance settings is due. Maintenance settings will be re-accumulated after clearing the alarm.



#### 3.2.3 Control System Settings



### 3.2.4 Emergency Setting

Emergency Setting			
Signal Fault Action			Setting Range : Stay Put, Fail-safe Position,
Stay Put		$\longrightarrow$	Preset Position
Emergency Action			Setting Range : Run to Fully Closed, Run to Fully
Run to Fully Closed	·	$\longrightarrow$	Open, Stop Running, Disable ESD
Signal Fault Position			Signal
0	% Confirmed	$\longrightarrow$	Setting Range : 0 to 100
Motor Thermal Alarm	Disable 🚺		
120	°C Confirmed	$\longrightarrow$	Setting Range : 0 to 120
Emergency Signal Setting	NO 🔽		

#### 3.2.5 Close / Open Setting



Menu	Instruction			
RPM Setting (LV)	Five speeds can be chosen and set from LV0 to LV4.			
Emergency RPM Setting (LV)	When an ESD signal is received, the actuator will run to the desired position based on the setting of "Emergency Action" and RPM can be set from LV0 to LV4.			
Travel Limit (%)	Set the travel limit-Open /Close and the setting range is from $80\%$ to $98\%$ / $2\%$ to $20\%$ .			
Limit Parameter Value	This is the position parameter stored in the software instead of the output shaft turns and can be read only.			
Jam Clearance Retries	<ul> <li>When a torque overload occurs, a retry sequence will be initiated by setting the parameters as following:</li> <li>Set to 0: The actuator will stay put and send a warning message when a torque overload occurs.</li> <li>Set to 1 2, 3, 4, or 5: The actuator will move back for 3% of the entire travel and then move forth to attempt to fix the jammed valve repeatedly by 1, 2, 3, 4, or 5 tries. In case of failure to pass the block, the actuator will run to opposite direction about 3% of stroke and stop running to send a warning message</li> </ul>			
	The actuator in CLOSE / OPEN and position can be set to trip by Position or			
Seating Type	Torque.			
Torque Limit	The tripping torque in end position of CLOSE / OPEN could be set from 30% to 100% and default settings are 100% for Close and 50% for Open.			
Torque Limit - Middle	The tripping torque in CLOSE / OPEN mid-travel could be set from 30% to 100% and the default setting is 50%. If the actuator is stuck in the mid-travel (per tripping torque setting), the actuator will perform the Retry function until programmed number of tries set in "Jam Clearance Retries" Tis reached.			
Close Tightly	As long as the actuator runs to the desired end position, the actuator will continue to run whether the end position command is cancelled or the STOP command from remote control system is received until a torque overload occurs, 0% position has been reached or a reversal operation command is received. The default setting is disable and either OPEN or CLOSE direction can be chosen.			
Close Direction	Define the rotation direction of the output shaft and either "CW to Close" or "CCW to Close" can be chosen. The default setting is "CW to Close".			

### 3.2.6 System Control Setting

Systme Control Setting Remote Control Setting Digital Permanent	Switch to enable or disable remote control (Disable means in local control mode).
Set A/I Sensitivity 5.0 Digital Input Channel Channel Analog Input Channel	Switch to NO (Normal Open) or NC (Normal Close) to set the digital / analog input channels and analog output channel.
Channel 2 Analog Output Channel Disabled	
Analog Signal Type (CH2)	Switch to CH1 or CH2 to set the signal types.

Menu	Description
Remote Control Setting	Digital Permanent, Digital Pulse Input, Analog Input, Modbus or Profibus can be chosen.
Set A/I Sensitivity	The highest sensitivity is set at 0.0% and the lowest is set at 5.0%. The default setting is 0.5%.
Digital Input Channel	Switch to NO (Conducting) or NC (Non-conducting) and Disable, Channel 1or Channel 2 can be chosen for digital / analog input channels and analog output channel.
Analog Input Channel	Three types can be chosen as follows: Disabled, channel 1 or channel 2.
Analog Output Channel	Three types can be chosen as follows: Disabled, channel 1 or channel 2.
A/I Signal Type	Six types can be chosen as follows: 0 - 20 mA, 4 - 20 mA, 0 - 5V, 1 - 5V, 0 -10V or 2 - 10 V.
A/O Signal Type	Six types can be chosen as follows: 0 - 20 mA, 4 - 20 mA, 0 - 5V, 1 - 5V, 0 - 10V or 2 - 10 V.

#### 3.2.7 Relay Contact Setting

• Each relay contact can be assigned to different Relay Mode, Normal Close or Normal Open. There are 17 relay output modes could be chosen and default setting is Disable. The function of each mode is as below table.

Relay Contact Setting	<b>└──→</b>	Switch to CH1 or CH2.	
Relay Contact	· ·		
Torque Trip			
Relay Contact 2 NC	]→[		
Motor Overheat		Switch to NO (Normal Open) (Normal Close) to set the relay	Switch to NO (Normal Open) or NC
Relay Contact 3 NO			(Normal Close) to set the relay contact
Closing			
Relay Contact 4 VO			
Opening			

No	Function	Description
1	Disable	Relay has no function.
2	Run to Fully Closed	Fully-closed position.
3	Run to Fully Open	Fully-open position.
4	Torque Trip-CL Mid	Torque overload in CLOSE Direction and stops running.
5	Torque Trip-OP Mid	Torque overload in OPEN Direction and stops running.
6	Torque Trip	Torque overload in either OPEN or CLOSE Direction and stops running.
7	Fault	Error has occurred.
8	Signal Flash	Relay contact is activated every second.
9	Ready	Motor is normal, handwheel lever disables and limit position setting is completed, which means the actuator is ready for electrical operation.
10	Remote Selected	Output signal for remote control.
11	Motor Overheat-Stop	The motor will stop running when its temperature is higher than $135^{\circ}$ C (275°F).
12	Motor Overheat	If the motor temperature exceeds the setting value, the motor will run at the lowest speed until its temperature is lower than the setting value.
13	Maintenance Due	One of maintenance settings is detected.
14	Closing	The valve is running to close direction.
15	Opening	The valve is running to open direction.
16	D/I Module Fault	Input Signal Not Found.
17	A/I Module Fault	Input Signal Not Found.



SUN YEH ELECTRICAL IND. CO., LTD.

No.68, Ln. 854, Sec. 1, Shatian Rd., Dadu Dist., Taichung City 432403, Taiwan Tel: +886-4-26985666 Fax: +886-4-26983668 E-mail: service@sunyeh.com



www.sunyeh.com