


- Note:
- (1). "N" connects to 1, "L" connects to 7.
 - (2). "L" connects to 3 for "OPEN", "L" connects to 4 for "CLOSE".
 - (3). Using less than 3A current for "A,B,C,E,F".
 - (4). Please wire terminal 7 as it is the power source for both power board and heater; otherwise, the actuator will not operate.



Wiring Diagram NO: 01-020-17-02-02-03-3-001

Rev	1.0	Signature	Date	OM1、OMA、OMAM Power Supply: 110~120VAC 1-Phase Floating Control 75% Duty Cycle
Designed				
Drawn	Guan Wei	2018/08/02		
Checked	Ming Hung	2018/09/01		
Approved				



SUN YEH ELECTRICAL IND. CO., LTD.
TEL: +886-4-2698-5666
FAX: +886-4-2698-1188