

| 型號              | 電壓                 | 控制模式 / 啟動頻率                     | 配線圖 |
|-----------------|--------------------|---------------------------------|-----|
| OM-1、OM-A、OM-AM | 110-120VAC         | ON-OFF/Floating, 30% duty cycle | ↓   |
|                 | 110-120VAC         | ON-OFF/Floating, 75% duty cycle | ↓   |
|                 | 220-240VAC 1-PHASE | ON-OFF/Floating, 30% duty cycle | ↓   |
|                 | 220-240VAC 1-PHASE | ON-OFF/Floating, 75% duty cycle | ↓   |
|                 | 110-120VAC         | Modulating, 75% duty cycle      | ↓   |
|                 | 220-240VAC 1-PHASE | Modulating, 75% duty cycle      | ↓   |

| 型號                                       | 電壓                 | 控制模式 / 啟動頻率                                           | 配線圖 |
|------------------------------------------|--------------------|-------------------------------------------------------|-----|
| BM-2, OM-F, OM-G,<br>OM-H, OM-2 to OM-13 | 110-120VAC         | ON-OFF/Floating, 30% duty cycle                       | ↓   |
| OM-2 to OM-8, OM-H                       | 110-120VAC         | ON-OFF/Floating, 75% duty cycle                       | ↓   |
| OM-9 to OM-13                            | 110-120VAC         | ON-OFF/Floating, 50% duty cycle                       | ↓   |
| BM-2, OM-F, OM-G,<br>OM-H, OM-2 to OM13  | 220-240VAC 1-PHASE | ON-OFF/Floating, 30% duty cycle                       | ↓   |
| OM-2 to OM-8, OM-H                       | 220-240VAC 1-PHASE | ON-OFF/Floating, 75% duty cycle                       | ↓   |
| OM-9 to OM-13                            | 220-240VAC 1-PHASE | ON-OFF/Floating, 50% duty cycle                       | ↓   |
| BM-2, OM-2 to OM-13,<br>OM-F, OM-G, OM-H | 220-240VAC 3-PHASE | ON-OFF/Floating, 30% duty cycle                       | ↓   |
| BM-2, OM-2 to OM-13,<br>OM-F, OM-G, OM-H | 380-415VAC 3-PHASE |                                                       | ↓   |
| BM-2, OM-2 to OM-13,<br>OM-F, OM-G, OM-H | 440-480VAC 3-PHASE |                                                       | ↓   |
| OM-2 to OM-8, OM-F,<br>OM-G, OM-H        | 110-120VAC         | Modulating, 30% duty cycle                            | ↓   |
| OM-2 to OM-8, OM-H                       | 110-120VAC         | Modulating, 75% duty cycle                            | ↓   |
| OM-9 to OM-13                            | 110-120VAC         | Modulating, 50% duty cycle                            | ↓   |
| OM-2 to OM-8, OM-F,<br>OM-G, OM-H        | 220-240VAC, 1-PH   | Modulating, 30% duty cycle                            | ↓   |
| OM-2 to OM-8, OM-H,<br>OM-9 to OM-13     | 220-240VAC, 1-PH   | Modulating, 75% duty cycle or<br>50% duty cycle       | ↓   |
| OM-2 to OM-13, OM-H                      | 220-240VAC, 3-PH   | Modulating with local control unit,<br>30% duty cycle | ↓   |
| OM-2 to OM-13, OM-H                      | 380-415VAC, 3-PH   |                                                       | ↓   |
| OM-2 to OM-13, OM-H                      | 440-480VAC, 3-PH   |                                                       | ↓   |

電壓 24V 的驅動器有兩種極性的電子板。如果接線錯誤，會損壞驅動器。請洽銷售代表確認電子板類型並索取正確的配線圖。